

For easier fan installation, remove temporarily the black twist tie from the cable bundle and

release at least one loop. Then tie the bundle back, see the picture.

Before you move to the next step, take an Allen key and **GENTLY PUSH** the motor cable to the channel to create space for the fan cable.

