

- Insert the FS-lever in the body.
- Secure the part with a M3x18. Tighten it, but ensure the lever can move freely.
- The M3x18 screw is secured into the plastic part without the nut.
- WARNING: make sure the following procedure is done right, otherwise the **filament sensor** won't work!!!
- Insert the bigger magnet (20x6x2) in the Extruder-body, it will stick out:
 - Incorrect setup: magnets are attracting each other, thus the lever is pulled to the left.
 - Correct setup: magnets are repelling each other, thus the lever is pushed to the right.

