






- Take the Y-carriage including smooth rods with rod holders and place them in YZ-frame. Make sure, that two bearings are on the left side (see the picture, there are two pairs of the screw holes on the left and one pair on the right).
- Secure each front holder with two M3x10 screws. Tighten both screws equally, but not **completely.** We will tighten them fully later on.
- Insert the M3x10 screw into the hole in each front holder and tighten it.
- Take the second pair of the Y-rod-holders and secure them with M3x10 screws on the rear plate (with shorter extrusions). Tighten both screws equally, but not completely. We will tighten them fully later on.
- Insert the M3x10 screw into the hole in each rear holder and tighten it.
- In case the M3nS nuts keep falling out, please flip the frame upside down. Tighten both (i) printed parts and then return the frame to the previous position.



https://help.prusa3d.com/guide/2a-y-axis-assembly_406654#407849