

- **IMPORTANT:** proper alignment of the smooth rods is crucial to reduce noise and overall friction.
- Ensure all M3x10 screws on Y-holders are slightly loosened, so the printed parts are able to move.
- Move the Y-carriage back and forth across the entire length of the smooth rods to align them.
- Then move the carriage to the front plate and tighten all screws in the front-Y-holders.
- Move the Y-carriage to the rear plate and tighten all screws in the back-Y-holders.

