

- Note this step is optional for now. We recommend mounting the feet now to protect the surface on your table (workbench). However, you need to lift the frame up before each turn.
- There will be extra step at the end of the assembly to remind you of the antivibration feet.
- For this step, please prepare:
 - Antivibration foot (4x)
- Turn the YZ frame on the side and insert the antivibration foot. Insert and turn 90 degrees to lock it in place.
- Repeat this process on all 4 feet. Place them 2-3 cm from the end of each extrusion.

