

- Place the FS-cover on the extruder and align it according to the picture.
- Insert the M3x10 screw (mind the correct hole) and tighten it.
- Tip: If you can't reach the nut, try to align it using an Allen key or pulling it up using a longer full-threaded screw from the spare bag.

