

- WARNING: Printed parts aren't the same! There is a left and right oriented piece. See the markings on the parts. Also note the correct orientation of the frame, the "PRUSA" logo and the safety sticker must be facing towards you.
- ★ For the following step, please prepare:
- Z-axis-bottom-left (1x)
- Z-axis-bottom-right (1x)
- M3x10 screw (6x)
- Place the printed parts next to the frame. See the left (L) and right (R) marking on the printed parts.
- Tighten each printed part with M3x10 screws. **Don't use excessive strength during tightening!** In case of increased resistance, try to place the screws from the other side to "clean up" the hole. Then return to the front side.

