

- For easier fan installation, remove temporarily the black twist tie from the cable bundle and release at least one loop. Then tie the bundle back, see the picture.
- Before you move to the next step, take an Allen key and **GENTLY PUSH** the motor cable to the channel to create space for the fan cable.

