

- Insert the square nut all the way in.
- Insert the M3x30 screw. For now, we need the screw just to hold in place. Do not tighten the screw fully. Leave a 2 mm (0.079 inch) gap between the screw head and the plastic part. We will adjust the final position later.

