

- Rotate the frame with longer extrusions towards you.
- Place the front plate on the extrusions and secure it with M5x16r screws, **DON'T TIGHTEN** them yet!
- Now, tighten the screws fully, but **ON A DIAGONAL**, see the second picture. As soon as you finish the first, tighten the second pair. Then proceed to the second long extrusion.
 - Be cautious when tightening these screws to avoid damaging the Allen key slot. Ensure the Allen key is fully inserted into the screw head. Tighten the screw firmly but gently.

