

- Insert the bearing into the bearing clip and the pocket.
- The correct bearing orientation: When placing bearings onto the Y-carriage, make sure that they are oriented as shown in both pictures. The tracks (rows of balls) have to be on the sides.
- The incorrect orientation: Avoid placing the bearing like in the last picture! This orientation with a single row of balls in the center of the hole will later increase the wear of the smooth rod, possibly creating a groove in it.

