

- Bend one end of the belt around M3x10 screw.
- Push it in the holder as in the picture. Use an Allen key to push the belt in.
- Make sure the bent part and the end are within the width of the printed part.
- Teeth on the belt must be facing up!
- Tighten the screw until you reach the nut, don't over tighten the screw, you will deform the belt.
- Hold the nut from the other side until the screw reaches its thread.

