

- Locate the hole for the NYLON filament just above the bottom bearing. Refer to the picture to make sure it is the correct one. Using the smallest Allen key, ensure there are no obstacles inside.
- Using the pliers **insert the NYLON filament with the pointed end into the slot**. Twist the filament while pushing it in. Hold the extruder with your other hand.
- **BE EXTREMELY CAREFUL** as the pliers tend to slide and you can easily damage the wires!!!
  - To check if the filament is seated properly, gently pull it with your hand. The X-axis should bend a little, but the filament must remain in the slot.
  - If you have issues, try to adjust the tip on the filament.

