







- Insert two M3x6 screws into the bearing clip screw holes.
- Note the three pockets for the bearings in the Y-carriage.
- Attach the bearing clip on one of the cutout and tighten the screws only a few turns.

