

- Before we proceed further, let's make a final check. **IT IS VERY IMPORTANT** to have extrusions on the correct side of the frame.
- Long extrusions must be on the side of the frame with the Prusa logo and the safety sticker, also ensure longer extrusions are closer together.
- Short extrusions must be on the side of the frame with the hexagonal recesses, also ensure shorter extrusions are further away from each other.

