

- Insert SuperPINDA sensor in the holder. Exact position doesn't matter, we will adjust it later.
- Tighten the M3x10 screw, but just slightly.
- Create a loop on the cable from the sensor.
- Push the cable in the channel together with the fan cable.

