

- **▲** For the following steps, please prepare:
- X-axis motor (1x)
- GT2-16 pulley (1x)
- Ensure you are using the correct motor, there is a label on the bottom of the casing. The reason is, each motor has different cable length.

