



- **▲** For the following steps, please prepare:
- Hotend fan (1x)
- M3x14 screw (3x)
- Make sure you are using the correct screws.
- (i) Keep the cable in a bundle for now.

