



- **▲** For the following steps, please prepare:
- X-carriage-back (1x)
- Cable-holder (1x)
- M3x40 screw (1x)
- M3n nut (1x)

