

- Take the Y-motor-holder and place it on the rear plate (short extrusions).
- Ensure the correct orientation, the motor shaft must be facing towards the aluminium extrusion with the PSU holders.
- Secure Y-motor-holder with two screws M3x10.

