

- Take the Y-belt-holder (smaller of the two printed parts).
- Insert M3n nut, all the way in.
- Insert M3nN nyloc nut, all the way in.
- (i) Use the screw pulling technique.

