

- **▲** For this step, please prepare:
- Extruder-cover (1x)
- M3nS nut (1x)
- Slide the nut all the way in.
- Ensure correct alignment using the Allen key.
- Leave the hole on the "arm" empty for now. We will use it later, while assembling a print fan.

