

- For the following steps, please prepare:
- Y-axis motor (1x)
- Y-motor-holder (1x)
- M3x10 screw (4x)
- M3n nut (2x)
- Ensure you are using the correct motor, there is a label on the bottom of the casing. The reason is, each motor has different cable length.

