

- Open one end of the textile sleeve and slide it on the cable bundle leading from the extruder.

 Don't forget to include the black nylon filament inserted earlier!
- Leave the cables from the hotend out for now.
- Length of the first wrap should be slightly longer than the cable-holder part, about 5 cm is enough.
- Gently twist the sleeve to make it smaller and tighter around the cables, orient the sleeve's seam downwards, then slide the sleeve towards the extruder.
- Take 3 zip ties and insert them into the lower row of holes on the cable-holder.
- Twist the sleeve again (without twisting the cables inside) and tighten the zip ties.
- **IMPORTANT:** Cut the remaining part of each zip tie using pliers as closest to its head as possible. Note the correct position of each zip ties's head (slightly off-centre to the left).

