

- Rotate the frame with longer extrusions towards you.
- Take the Y-belt-idler and place it on the front plate. **Note there is a mark (circle) on the printed part facing up.**
- Secure the Y-belt-idler with two M3x10 screws. Tighten the screws until the printed part reaches the surface of the plate.

