

- Let's use this opportunity to check once more the proper alignment of the filament and the Bondtech gear.
- Push the filament from the top, through the Bondtech into the PTFE tube.
- Check the alignment and if needed, adjust the position.
- ▲ Tighten the screw, but be careful, you can easily strip it.
- **REMOVE** the filament.





Next →

