

- Ensure the frame with shorter extrusions is rotated towards you.
- Place the rear plate on the extrusions and secure it with M5x16r screws, **DON'T TIGHTEN** them yet!
 - Orient the part so that the sticker is on the back of the printer.
- Now, tighten the screws fully, but **ON A DIAGONAL**, see the second picture. As soon as you finish the first, tighten the second pair. Then proceed to the second short extrusion.
 - Be cautious when tightening these screws to avoid damaging the Allen key slot. Ensure the Allen key is fully inserted into the screw head. Tighten the screw firmly but gently.

