

CHECKLIST

- Install (correct) USB drivers—typically CP2102 or CH340g
- Connect computer and ESP8266 to the same network
- ► [Windows] Install Apple Bonjour for Windows: https://support.apple.com/downloads/bonjour-for-windows
- Restart Arduino IDE
- ▶ ESP.restart() fails after uploading firmware over USB. Restart the ESP8266 board and it'll work!