## Lab 4: Alexandre TRUONG

Link to my Digital-electronics-2 GitHub repository:

https://github.com/AkaiRyussei/Digital-electronics-2

## Overflow times

1. Complete table with overflow times.


Module	Number of bits	1	8	32	64	128	256	1024
Timer/Counter0	8	16u	128u		1024u		4096u	16384u
Timer/Counter1	16	4096u	32768u		262144u		1048576u	4194304u
Timer/Counter2	8	16u	128u	512u	1024u	2048u	4096u	16384u

## Timer library

- 1. In your words, describe the difference between common C function and interrupt service routine.
  - Function: a block of executable code that can be called anywhere in the program.
  - Interrupt service routine: When an interrupt occurs, the current operations are suspended while the routine is executed. After the ISR is completed, the operations are resumed.
- 2. Part of the header file listing with syntax highlighting, which defines settings for Timer/Counter0:

```
* @name Definitions of Timer/Counter0
   * @note F_CPU = 16 MHz
   */
// WRITE YOUR CODE HERE
#define TIM0_stop()
                                                                                   TCCR0B &= ~((1<<CS02) | (1<<CS01) | (1<<CS00));
/** @brief Set overflow 16us, prescaler 001 --> 1 */
 \begin{tabular}{ll} $\#define TIMO\_overflow\_16us() &= $\sim((1<<CS02) \mid (1<<CS01))$; $TCCR0B \mid = (1<<CS00)$; $TCCR0B$; $TCCR0B$; $TCCR0B$; $TCCR0B$; $TCCR0B$; $TCCR0B$; $TCCR0
/** @brief Set overflow 128us, prescaler 010 --> 8 */
#define TIMO_overflow_128us() TCCR0B &= ~((1<<CS02) | (1<<CS00)); TCCR0B |= (1<<CS01);
/** @brief Set overflow 1ms, prescaler 011 --> 64 */
#define TIM0_overflow_1ms() TCCR0B &= \sim(1<<CS02); TCCR0B |= (1<<CS01) | (1<<CS00);
/** @brief Set overflow 4ms, prescaler 100 --> 256 */
 \begin{tabular}{ll} \#define TIMO\_overflow\_4ms() & TCCR0B \&= $$\sim((1<<CS01) \mid (1<<CS00))$; $TCCR1B \mid = (1<<CS02)$; $$
/** @brief Set overflow 16ms, prescaler // 101 --> 1024 */
/** @brief Enable overflow interrupt, 1 --> enable */
#define TIM0 overflow interrupt enable() TIMSK0 |= (1<<TOIE0);</pre>
/** @brief Disable overflow interrupt, 0 --> disable */
#define TIM0_overflow_interrupt_disable() TIMSK0 &= ~(1<<TOIE0);</pre>
```

3. Flowchart figure for function main() and interrupt service routine ISR(TIMER1\_OVF\_vect) of application that ensures the flashing of one LED in the timer interruption. When the button is pressed, the blinking is faster, when the button is released, it is slower. Use only a timer overflow and not a delay library.



## **Knight Rider**

1. Scheme of Knight Rider application with four LEDs and a push button, connected according to Multi-function shield. Connect AVR device, LEDs, resistors, push button, and supply voltage. The image can be drawn on a computer or by hand. Always name all components and their values!

