

drive access is attempted or there was an indication of a DOS error message, then the drives spindle system is probably defective.

THE DRIVE CANNOT ACCEPT OR REJECT A CD

POSSIBILITY: The motor mechanism of the drives is probably faulty

Troubleshooting:

- i. Check The assemble the assembly through the CD slot for any obstruction
- ii. Expose the assembly and check each linkage and motor drive gear to remove any obstruction if there is
- iii. Disconnect the geared DC motor assembly and try moving the load/unload mechanism by hand. If you feel any resistance or obstruction, you should tract it down by eye and by feel. Replace any worn out or damage mechanism or the entire load/unload assembly
- iv. Check the gear motor for any damage or blockage, broken or slipping gear teeth can interface with the transfer of force from the motor to mechanism. Replace the entire damage gear or assembly, or the DC rom drive outright.

THE CD CANNOT BE READ

Possibility: this problem might be due to a DOS level "sector not found" or "drive not ready" error.

Troubleshooting

- i. Check the CD itself to be sure that it is the right format inserted properly and physically clean.
- ii. Try another disc to configure the problem if a different disc read well, the trouble might be in or on the first disc itself. If not, gently clean the head optics following your drives manufactures guide.