



# Mechanics of Materials I: Fundamentals of Stress & Strain and Axial Loading

Dr. Wayne Whiteman Senior Academic Professional and Director of the Office of Student Services Woodruff School of Mechanical Engineering





# **Module 45 Learning Outcome**

Solve a engineering problem when thermal effects are present

**Example:** 

Bar BC is aluminum and has a cross sectional area of 2000 mm<sup>2</sup> and a modulus of elasticity of 70 GPa.  $\sigma_{\text{alum yield}}$  = 280 MPa = 0.28 GPa.

Georgia Tech

The coefficient of thermal expansion of aluminum is  $\alpha = 22.5 \times 10^{-6}$ °C.


Bar DE is brass and has a cross sectional area of 1300 mm<sup>2</sup> and a

modulus of elasticity of 100 GPa.  $\sigma_{\text{brass vield}}$  = 100 MPa = 0.1 GPa.

The coefficient of thermal expansion of brass is  $\alpha = 17.6 \times 10^{-6}$ °C.

Bar ABDE can be considered rigid. Both the aluminum and brass ba

Bar ABDF can be considered rigid. Both the aluminum and brass bars are deformable. The weight of the bars can be assumed negligible in comparison to the forces they are supporting. Determine the axial stress in the aluminum and brass bars when the temperature decreases




# **Static Equilibrium Equations**

# Georgia Tech


## **Draw the FBD**


Assume tension in bars BC and DE



# **Static Equilibrium Equations**








# We need an additional equation



assume small deformations and therefore small angles





# similar triangles

$$\frac{\delta_{D_{total}}}{300} = \frac{\delta_{B_{total}}}{450}$$

$$1.5\,\delta_{D_{total}} = \delta_{B_{total}}$$

#### **Example:**

Bar BC is aluminum and has a cross sectional area of 2000 mm<sup>2</sup>

and a modulus of elasticity of 70 GPa.

 $\sigma_{\text{alum yield}}$  = 280 MPa = 0.28 GPa.


The coefficient of thermal expansion of aluminum is  $\alpha = 22.5 \times 10-6/^{\circ}C.$ 

Bar DE is brass and has a cross sectional area of 1300 mm<sup>2</sup> and a

modulus of elasticity of 100 GPa.  $\sigma_{\text{brass yield}}$  = 100 MPa = 0.1 GPa.

The coefficient of thermal expansion of brass is  $\alpha = 17.6 \times 10-6/^{\circ}C.$ 

Bar ABDF can be considered rigid. Both the aluminum and brass bars are deformable. The weight of the bars can be assumed negligible in comparison to the forces they are supporting. Determine the axial stress in the aluminum and brass bars when the temperature decreases by 30° C.



### **Equilibrium Equation**

$$3000\sigma_{BC}-1300\sigma_{DE}=270$$
 EQN [\*]

Georgia

Tech

300 mm

150 mm

# **Deformation/Compatibility Equation**

$$1.5\delta_{D_{total}} = \delta_{B_{total}}$$

# **Force-Thermal Displacement Relation**

$$1.5(\delta_{T_D} - \delta_{P_D}) = (-\delta_{T_B} + \delta_{P_B})$$

$$1.5 \left[ (17.6 \, x \, 10^{-6}) \, 30 (380) - \frac{\sigma_{DE}(380)}{100} \right] = \left[ (-22.5 \, x \, 10^{-6}) \, 30 (250) - \frac{\sigma_{DE}(250)}{70} \right]$$

$$3.57 \, \sigma_{BC} + 5.70 \, \sigma_{DE} = 0.470 \quad \text{EQN [**]}$$

#### **Example:**

Bar BC is aluminum and has a cross sectional area of 2000 mm<sup>2</sup> and a modulus of elasticity of 70 GPa.

 $\sigma_{\text{alum yield}}$  = 280 MPa = 0.28 GPa.

The coefficient of thermal expansion of aluminum is

 $\alpha = 22.5 \times 10-6/^{\circ}C.$ 

Bar DE is brass and has a cross sectional area of 1300 mm<sup>2</sup> and a modulus of elasticity of 100 GPa.

 $\sigma_{\text{brass yield}}$  = 100 MPa = 0.1 GPa. The coefficient of thermal expansion of brass is

the temperature decreases by 30° C.

 $\alpha = 17.6 \times 10-6/^{\circ}C.$ 

Bar ABDF can be considered rigid. Both the aluminum and brass bars are deformable. The weight of the bars can be assumed negligible in comparison to the forces they are supporting. Determine the axial stress in the aluminum and brass bars when **Equilibrium Equation** 

$$3000\sigma_{BC} - 1300\sigma_{DE} = 270$$
 EQN [\*]

Georgia

**Force-Thermal Displacement Relation** 

$$3.57\,\sigma_{BC} + 5.70\,\sigma_{DE} = 0.470$$
 EQN [\*\*

