Conteúdo

1 Introdução

2 Raspbian Startup

1. Open console

2. `sudo ifconfig enp2s0f0 10.0.0.2 netmask 255.255.255.0`

3. Configure by hand on Ubuntu wired connection settings

    (a) Details -> Disable *Connect Automatically*

    (b) IPv4 -> *IPv4 Method* to *Manual*

    (c) Set address to `10.0.0.2` and gateway to `255.255.255.0`

4. Run `ssh pi10.0.0.1` and use `raspberry` as password