Bialetti Gioia

Contents

Contents 1

Bill of Materials 2

Required tools 2

Disassembly procedure 3

1. Open outer shell . . . 3
2. Remove user parts . . . 3
3. Remove control panel . . . 3
4. Extract hydraulic circuit . . . 3
5. Extract PCB & wiring . . . 4
6. Extract thermoblock . . . 4
7. Disassemble thermoblock . . . 4

Bill of Materials

Bill of materials not requested at load time.

Required tools

- Soft cloth
- Torx T10 screwdriver
- Phillips PH1 screwdriver
- Plastic pry tool
- Hands
- JST connector tool
- Phillips PH0 screwdriver
- Container
- Hose clamp pliers
- Side cutters
- Heat-resistant gloves (precaution)
- 10 mm wrench
- Bench vice with soft jaws
- Hex key (typically 4 mm)
- Soft mallet
- Press / saw (destructive option)

Disassembly procedure

1. Open outer shell

Disassembling: Bialetti Gioia

Tools: Soft cloth, Torx T10 screwdriver, Phillips PH1 screwdriver, Plastic pry tool, Hands

1. Place the machine upside-down on a soft cloth so the bottom plate is accessible; remove any residual water from the tank seat to avoid leaks. *(Soft cloth)*
2. Unscrew the 4 Torx T10 screws located at the corners of the bottom plate. *(Torx T10 screwdriver)*
3. Unscrew the 2 Phillips PH1 screws behind the rear panel, near the power-cord grommet. *(Phillips PH1 screwdriver)*
4. Release the 4 internal plastic clips along the vertical edges by gently prying with a flat plastic tool. *(Plastic pry tool)*
5. Lift the upper shell vertically, keeping it parallel to the base, to separate it from the internal chassis. *(Hands)*

Extracted components: Outer shell

Continues as: Chassis (full)

2. Remove user parts

Disassembling: Chassis (full)

Tools: Hands, Phillips PH1 screwdriver

1. Lift out the 0.5 L removable water tank from its seat at the rear of the machine. *(Hands)*
2. Pull out the used-capsule drawer from the front-bottom slot. *(Hands)*
3. Release the 2 Phillips PH1 screws of the capsule lever / brewing-group assembly and lift it out. *(Phillips PH1 screwdriver)*

Extracted components: Water tank, Capsule drawer, Capsule lever

Continues as: Chassis (no user parts)

3. Remove control panel

Disassembling: Chassis (no user parts)

Tools: JST connector tool, Phillips PH0 screwdriver, Hands

1. Unplug the JST-XH 4-pin connector that links the front button board to the main PCB; press the latch before pulling. *(JST connector tool)*
2. Unplug the JST-PH 2-pin connector of the aluminium-capsule sensor, located just behind the capsule lever assembly. *(JST connector tool)*
3. Unscrew the 2 Phillips PH0 screws that hold the button panel to the front of the chassis. *(Phillips PH0 screwdriver)*
4. Slide the button panel forward and lift it out together with the integrated LED indicators and the capsule sensor. *(Hands)*

Extracted components: Button panel, Capsule sensor

Continues as: Chassis (no panel)

4. Extract hydraulic circuit

Disassembling: Chassis (no panel)

Tools: Container, Hose clamp pliers, Hands, Phillips PH1 screwdriver

1. Place a container under the chassis to catch ~30 mL of residual water that will drip from the tubing during removal. *(Container)*
2. Release the spring clamp on the silicone tube from the tank valve to the pump inlet; slide the tube off the barb. *(Hose clamp pliers)*

3. Release the spring clamps on the silicone tubes from the pump outlet to the flow meter, and from the flow meter to the thermoblock inlet. *(Hose clamp pliers)*
4. Unplug the 2-pin power connector that supplies the pump from the main PCB. *(Hands)*
5. Unscrew the 2 Phillips PH1 screws holding the pump bracket to the chassis, then lift the pump together with the flow meter and the tubing as a single hydraulic assembly. *(Phillips PH1 screwdriver)*

Extracted components: Vibration pump, Silicone tubing, Flow meter

Continues as: Chassis (no hydraulic)

5. Extract PCB & wiring

Disassembling: Chassis (no hydraulic)

Tools: JST connector tool, Phillips PH0 screwdriver, Side cutters, Hands

1. Unplug all remaining JST connectors from the main PCB: thermostat lead, thermoblock heater lead, pump triac lead. *(JST connector tool)*
2. Disconnect the mains input wires from the PCB screw terminals (LIVE / NEUTRAL / EARTH). *(Phillips PH0 screwdriver)*
3. Cut any cable ties that fix the wiring harness to the chassis ribs. *(Side cutters)*
4. Unscrew the 4 Phillips PH0 screws securing the PCB to its plastic tray and lift the board out. *(Phillips PH0 screwdriver)*
5. Pull the wiring harness and the power cord through the chassis cut-out as a single bundle. *(Hands)*

Extracted components: Main PCB, Wiring harness, Power cord

Continues as: Chassis (only thermoblock)

6. Extract thermoblock

Disassembling: Chassis (only thermoblock)

Tools: Heat-resistant gloves (precaution), Hands, 10 mm wrench, Phillips PH1 screwdriver

1. Verify the machine has been unplugged for at least 30 minutes so the thermoblock has fully cooled before touching the metal body. *(Heat-resistant gloves (precaution))*
2. Disconnect the two faston terminals of the heating element from the harness, and the 2-pin JST of the safety thermostat. *(Hands)*
3. Unscrew the brass nut at the thermoblock outlet (towards the brew chamber) using a 10 mm wrench; keep a cloth nearby for residual drips. *(10 mm wrench)*
4. Unscrew the 2 Phillips PH1 screws of the thermoblock bracket on the chassis side wall. *(Phillips PH1 screwdriver)*
5. Lift the thermoblock assembly vertically out of its seat. *(Hands)*

Extracted components: Chassis frame

Continues as: Thermoblock assembly

7. Disassemble thermoblock

Disassembling: Thermoblock assembly

Tools: Bench vice with soft jaws, Hex key (typically 4 mm), Soft mallet, Press / saw (destructive option)

1. Clamp the aluminium body in a bench vice with soft jaws to avoid marking the surface; keep the heating-element side accessible. *(Bench vice with soft jaws)*
2. Unscrew the safety thermostat from its threaded seat on the body; it comes out as a single threaded brass capsule. *(Hex key (typically 4 mm))*
3. Push out the heating element from its dedicated tunnel inside the aluminium body, gently tapping with a soft mallet if needed. *(Soft mallet)*
4. Separate the stainless-steel tube (water path) from the aluminium body; depending on the design, this may require a press or destructive cut. *(Press / saw (destructive option))*

Extracted components: Thermoblock fasteners, Heating element, Safety thermostat, Aluminium body, Stainless tube