

trivum Interface for JUNG Visu Pro - Guide

Setting up the trivum connection in JVP - step by step

This JUNG Visu Pro (JVP) process connection controls a **trivum multiroom audio system** via its built-in **mcenter HTTP/XML API** (documentation: <https://www.trivum.com/trivum/docs/en/mcenter-api.html>). JVP talks to the trivum system directly on the local network - no additional bridge server is required.

Per zone, the interface provides: on/off, mute, volume, source selection, transport (play/pause/stop/next/previous), multiroom grouping, and status readouts such as artist, track, album and cover. It also provides a central “all zones off” function and a prepared favorites list.

1. Requirements

- The trivum system (e.g. MusicCenter) must be reachable on the same local network as the JVP server.
- The trivum system’s IP address or hostname (e.g. 192.168.1.30).
- HTTP access to the trivum web interface works without additional credentials by default (port 80, unless changed).

2. Load the interface in JVP

- Open the interface editor and add/reload the **Trivum** connection (folder Interfaces\JVP-Trivium).
- If the connection was already open: reload the editor so the current InterfaceDescription.xml is picked up.

3. Enter the configuration

Navigate to **Configuration** in the tree:

- **trivum IP address / hostname**: the IP address or hostname from step 1.
- **HTTP port**: default 80, only change if the trivum web interface runs on a different port.
- **Number of trivum zones (total)**: the total number of physical zones in the trivum system (e.g. 4) - regardless of how many zone instances are created in the editor. This value is required for multiroom grouping (see chapter 7) and should be set correctly even if not every zone is mapped in JVP.

4. Find zone IDs

The easiest way is directly through the interface itself:

1. Set **List zones** (Configuration) to 1.

2. Under **Status → Zone list (ID + name)** a tab-separated list of all trivum zones, sorted by ID, appears with each zone's ID and its name as configured in trivum.
3. Copy the content - it can be pasted directly into Excel/a spreadsheet (tabs = column separators) or used as a cheat sheet when creating the zone instances (step 5).

Alternatively, the zone ID is also available directly in the trivum web configuration (Automation / trivum API).

5. Create zone instances in the JVP editor

Create a new **Zone** instance for every trivum zone you want to control (right-click the "Zone" folder → new instance):

- **Zone name:** internal display name of the zone in JVP (free text).
- **trivum zone ID:** the ID determined in step 4 (0-based, e.g. 0, 1, 2, ...).

6. Control and feedback

Every controllable value (on/off, mute, volume) exists twice:

- **Command point (On/Off, Mute, Volume):** writable, sends the command to trivum.
- **Feedback point** with the "Feedback" suffix (e.g. **Feedback On/Off**): read-only, populated only from the regular status poll (every 2 seconds per zone, round robin) with the actual trivum state.

This separation (KNX-style command value/feedback) prevents an external change (e.g. via the trivum app or a wall panel) from overwriting the value JVP last sent - the feedback point still always shows the real device state.

Feedback Mute stays empty if trivum does not return this value in the zone status (not guaranteed by the trivum API documentation).

Momentary commands (**On/Off, Mute, Play/Pause/Stop/Next/Previous, Join/Leave group, trivum command (numeric)**) additionally report back immediately (without waiting for the next poll) via **Feedback last command / Feedback command time**, showing which code was sent last.

7. Select a source

Enter the short name of the desired trivum source into **Select source**. The most important prefixes per the trivum API documentation:

Prefix	Meaning	Example
a	Analog input	a1, a3
f	trivum favorite	f2 (see chapter 9)
p	FM tuner preset	p5
i	TuneIn webradio preset	i2
y	trivum playlist	y2
s	Default stream source	s
t	Default FM tuner	t

The leading @ that the trivum API technically requires (e.g. @f2) is added automatically by the interface if missing - both f2 and @f2 work.

For any other trivum “multi command” code (see API documentation, section “ZoneCommand”) that is not mapped to its own data point, use **trivum command (numeric)**.

8. All zones off

Set **Status → All zones off** to 1 to switch off all trivum zones at once (trivum command ZONECMD_ALLOFF). **Feedback: All zones off sent** shows the time of the last sent telegram.

9. Favorites

- Set **Refresh favorites list** (Favorites) to 1 to re-fetch the trivum favorites (also happens automatically on startup).
- **Favorites list** shows all found favorites as a list of “@fN: Name [Service]”.
- Additionally, every favorite is also available individually as **Favorite @f1 ... Favorite @f20**, so each favorite can be bound directly to its own control element in the visualization without having to parse the combined list.
- To play a favorite, enter its short name (e.g. f3) into the zone’s **Select source** (see chapter 7).

10. Multiroom grouping

Two different approaches are available:

Simple (no target selectable):

- **Join group**: this zone joins the group of the last active zone.
- **Leave group**: this zone leaves its current group.

Targeted (target zone freely selectable, via trivum createGroup.xml):

- **Take music from zone**: enter the source zone’s trivum zone ID - this zone takes over its music (“Get music from channel X”).
- **Send music to zone**: enter the target zone’s trivum zone ID - the target zone takes over this zone’s music (“Send music to channel X too”).
- **Detach from group**: detaches this zone from its current group in a targeted way, without affecting other, unrelated groups in the system.

Feedback group status shows the current trivum groupmaster ID of this zone (255 = no group, if reported that way by trivum).

Note: this targeted grouping relies on **Number of trivum zones (total)** (Configuration, chapter 3) being set correctly - otherwise the grouping request can incorrectly include or omit other, unrelated zones.

11. Testing

- Switch a zone via **On/Off** and check that **Feedback On/Off** follows after the next poll (at most 2 seconds × number of zones).
- Change **Volume** and check **Feedback Volume**.
- Set a source via **Select source** (e.g. s or a favorite, see chapter 7/9) and check **Current source, Artist, Track**.
- **Status → Connection** should show “connected”; **Last update**

counts up on every successful poll.

- If a query fails, **Status** → **Last error** shows the error text of the last failed trivum call.

Troubleshooting

Symptom	Cause/solution
Connection stays “disconnected”	Wrong IP address/hostname or port, trivum system not reachable on the network, or the HTTP resource not correctly wired up in InterfaceDescription.xml (see Status → Last error)
Zone does not respond	Wrong/empty trivum zone ID , or the instance folder was not reloaded after creation
Feedback Mute always stays empty	trivum does not return this value in the queried zone status - not a defect of the interface (see chapter 6)
Source is not applied	Short name misspelled (see table in chapter 7), or the source does not exist in this configuration
Grouping includes the wrong/too few zones	Number of trivum zones (total) does not match the actual number of zones in the trivum system (see chapter 10)
Favorites list is empty	Trigger Refresh favorites list again; check whether any favorites are actually configured in the trivum system