

NOTES:

1 - Multiple switches can be used in parallel. Actions in any of them will change the LOAD output state.

2 - Multiple loads can be connected in parallel, but the total current must be less than 5A.

3 - When there is no need for a switch, the SW input can be left unconnected.

Author: Alan Carvalho	HAP ON-OFF Module Wiring Diagram	File: hap_on-off_module_diagram
Date: 30/04/2026		Page: 1/1