For Network Manager Install:


Codes:

```
sudo apt-get update && apt-get upgrade
sudo apt-get install network-manager network-manager-gnome
sudo systemctl stop dhcpcd.service
sudo systemctl disable dhcpcd.service
sudo systemctl enable NetworkManager.service
sudo systemctl start NetworkManager.service
```

For VNC remote service:

Codes:

sudo raspi-config



Go to interface Options

Click VNC and enable it.

Go to Advanced Options and click on Expand Filesystem

Then it will ask you to restart and restart it.