





## IO expanders





Use Open-drain config for interrupt

















E-ink display: https://www.waveshare.com/wiki/File:2.7inch\_e-Paper\_HAT\_Schematic.pdf

Note: display connector pin assignment is contrary to that of display datasheet, because connector flips and connects to bottom of PCB

Sheet name	Display	
Project name	OpenIMU	4
Contact	V-P.Rheaume@USherbrooke.ca	
Rev 1.0 D	ate 2018-06-04   Sheet 8 of 8	

4