
ADJUSTMENT

POINTS AND METHODS OF ADJUSTMENT MDS-CPU PCB

Game Option Switch Settings



CAUTION: Make sure the Software ROMs and Custom ICs are inserted properly.

SW1:MAIN

(Left side for two monitor game Not used for one monitor game)

SW2:SUB

(Right side for two monitor game Also used for one monitor game)

MDS FOR VS.FROM BELOW

			SW1 (SW2)							
		1	2	3	4	5	6	7	8	
Free Play		OFF	OFF							
Credit / Coin 1/1		OFF	ON							
	1/2	ON	OFF							
	1/4	ON	ON							
PPU	RP2C04-0001			OFF	OFF	OFF				
	RP2C04-0002			ON	OFF	OFF				
	RP2C04-0003			OFF	ON	OFF				
	RP2C04-0004			ON	ON	OFF				
	2C03/2C05			OFF	OFF	ON				
	2C02 (NES)			ON	OFF	ON				
Disable Music							ON			
Disable SFX								ON		
Disable Attract Mode Sound									ON	