
# ADJUSTMENT -

## POINTS AND METHODS OF ADJUSTMENT MDS-CPU PCB

### Game Option Switch Settings



CAUTION: Make sure the Software ROMs and Custom ICs are inserted properly.

#### SW1:MAIN

(Left side for two monitor game Not used for one monitor game)

#### SW2:SUB

(Right side for two monitor game Also used for one monitor game)

#### MDS FOR VS.FROM BELOW

		SW1 (SW2)							
		1	2	3	4	5	6	7	8
Free Play		ON							
Credit / Coin 1/1			OFF						
	1/2		ON						
PPU	RP2C04-0001			OFF	OFF	OFF			
	RP2C04-0002			ON	OFF	OFF			
	RP2C04-0003			OFF	ON	OFF			
	RP2C04-0004			ON	ON	OFF			
	2C03/2C05			OFF	OFF	ON			
	2C02 (NES)			ON	OFF	ON			
Disable Music							ON		
Disable SFX								ON	
Disable Attract Mode Sound									ON