

CONVERSIONI

BIN - DEC

$$\begin{array}{r} 32 \quad 16 \quad 8 \quad 4 \quad 2 \quad 1 \\ 70 \quad 10 \quad 11 \\ \dots 2^5 \quad 2^4 \quad 2^3 \quad 2^2 \quad 2^1 \quad 2^0 \end{array}$$

$$32 + 8 + 2 + 1 = 43$$

DEC - BIN

43 = 101011

RESTO

43	1
21	1
10	0
5	1
2	0
1	1
0	

HEX - DEC

01CF = 256 + 192 + 15 = 463

12-16=192
256
15-1=15

0=0
1=1
2=2
3=3
4=4
5=5
6=6
7=7
8=8
9=9

A=10
B=11
C=12
D=13
E=14
F=15

DEC HEX

DECAL - BIN

5, 14 = 101, 0010

5	1	↑	0,14 · 2 = 0,28	0
2	0		0,28 · 2 = 0,56	0
1	1		0,56 · 2 = 1,12	1
0			0,12 · 2 = 0,24	0

BIN - DECAL

COMPLEMENTO A1

-90 = 10100101

90 = 01011010

$$\begin{array}{r} 11111111 - \\ 01011010 = \\ \hline 10100101 \end{array}$$

COMPLEMENTO A2

PRENDI IL COMPLEMENTO A1 E

$$\begin{array}{r} 10100101 + \\ \hline 10100110 \end{array}$$

SEGRE PER FARE L'ADDEZIONE
5-3 E SI TOGLIE L'OVERFLOW

ADDIZIONE

$$\begin{array}{r} 1 \quad 1 \\ 1010 + \\ 101 + \\ \hline 11100 = \\ 101011 \end{array}$$

SOTTRAZIONE

$$\begin{array}{r} -1 \\ 11011 - \\ 110 = \\ \hline 0101 \end{array}$$

$$\begin{array}{r} -1-1-1 \\ 11010 - \\ 11 = \\ \hline 0101 \end{array}$$

MOLTIPLICAZIONE

$$\begin{array}{r} 1010 \cdot \\ 101 = \\ \hline 110010 \end{array}$$

DIVISIONE

$$\begin{array}{r} 1101111 \\ 11 \overline{) 1100111} \\ \underline{00} \\ \underline{00} \\ 01 \\ \underline{00} \\ 11 \\ \underline{11} \\ 00 \end{array}$$