Finite representation of real numbers

Dr. Ing. Rodrigo Gonzalez

rodralez@frm.utn.edu.ar

Técnicas Digitales III


Universidad Tecnológica Nacional, Facultad Regional Mendoza.

Resumen

Coder

- Coder
- 2 Integers
- Fixed-point
 - Fractional point
 - Scale factor
 - Dynamic range
 - Overflow and underflow
 - Addition
 - How to avoid overflow
 - Multiplication
 - Accumulator

- How to avoid underflow
- Floating-point
 - Number Representation
 - Standards
 - Normalized Form
 - De-normalized Form
 - Rounding schemes
 - Dynamic range
 - Precision
 - Sum of two floating-point positive numbers
- Fixed-point vs floating-point



Unsigned integers

 An N-bit binary word can represent a total of 2^N separate values.

Fixed-point

Range: 0 to 2^N − 1

•
$$n_{10} = 2^{N-1}b_{N-1} + 2^{N-2}b_{N-2} + \dots + 2^{1}b_{1} + 2^{0}b_{0}$$

2's complement signed integers

• Range:
$$-2^{N-1}$$
 to $2^{N-1} - 1$.

•
$$n_{10} = -b_{N-1}2^{N-1} + \sum_{i=0}^{N-2} b_i 2^i$$

Bit Pattern	Unsigned	2's Complement		
0000 0000	0	0		
0000 0001	1	1		
0000 0010	2	2		
•	•	•		
•	•	•		
0111 1110	126	126		
0111 1111	127	127		
1000 0000	128	-128		
1000 0001	129	-127		
•	•	•		
•	•	•		
1111 1110	254	-2		
1111 1111	255	-1		

Representation (2)

How much bits are needed to represent $-\alpha_{min} \leq \alpha \leq \alpha_{max}$?

$$N = floor(log_2(max([\alpha_{min}, \alpha_{max}])) + 2)$$

MATLAB

- \bullet » a_m = 15; a_M = 15;
- ② » N = floor (log2 (max ([a_m , a_M])) + 2);

"Q" notation

To represent numbers with fractional parts, one simply has to assume that the [implicit] binary point at various bit positions along the data word allows the scale of representation to be binary point is located somewhere to the left of b_0 . Assume is a key word here.

The fractional notation can be applied to the 2's complement notation.

Qm.n

- *m* represents the number of bits to the left of the binary point.
- n represents the number of bits to the right of the binary point.
- The weights of bits that are to the right of the binary point are negative powers of 2: $2^{-1} = \frac{1}{2}$, $2^{-2} = \frac{1}{4}$..., etc.
- This naming convention does not take the MSB of the number (sign bit) into account. A Qm.n notation therefore uses m + n + 1 bits.
- Precision: 2^{-n} .
- Range: -2^m to $2^m 2^{-n}$.

Fractional point

Coder

"Q" notation, examples

For instance:

- Q0.15 (Q15)
 - 16 bits;
 - Range: -1 to 0.99996948;
 - Precision: 1/32768 (2⁻¹⁵).
- Q3.12
 - 16 bits;
 - Range: -8 to 7.9998;
 - Precision: 1/4096 (2⁻¹²).
- Q0.31 (Q31)
 - 32 bits:
 - Range: -1 to 0.99999999534339;
 - Precision: 4.6566129e-10 (2⁻³¹).

Precision examples

Format (N.M)		Largest positive value (0x7FFF)	Least negative value (0x8000)	Precision (0x0001)		DR(dB)
1	15	0,999969482421875	-1	3,05176E-05	2^-15	90,30873362
2	14	1,99993896484375	-2	6,10352E-05	2^-14	90,30873362
3	13	3,9998779296875	-4	0,00012207	2^-13	90,30873362
4	12	7,999755859375	-8	0,000244141	2^-12	90,30873362
5	11	15,99951171875	-16	0,000488281	2^-11	90,30873362
6	10	31,99902344	-32	0,000976563	2^-10	90,30873362
7	9	63,99804688	-64	0,001953125	2^-9	90,30873362
8	8	127,9960938	-128	0,00390625	2^-8	90,30873362
9	7	255,9921875	-256	0,0078125	2^-7	90,30873362
10	6	511,984375	-512	0,015625	2^-6	90,30873362
11	5	1023,96875	-1024	0,03125	2^-5	90,30873362
12	4	2047,9375	-2048	0,0625	2^-4	90,30873362
13	3	4095,875	-4096	0,125	2^-3	90,30873362
14	2	8191,75	-8192	0,25	2^-2	90,30873362
15	1	16383,5	-16384	0,5	2^-1	90,30873362
16	0	32767	-32768	1	2^-0	90,30873362

Scale of representation

- There is no difference at the CPU level between a fractional and an integer representation.
- The difference is based on the concept of scale, which is almost completely in the head of the designer.
- Values represented in Qm.n notation can be seen as a signed integer simply divided by 2ⁿ, the inverse of precision.
- In fact, the scale factor can be an arbitrary scale that is not a power of two.
- Example: 16-bit 2's complement numbers between 8000H and 7FFFH can represent decimal values between -5 and +5, where the scale factor is 5/32768 (5/2¹⁵).

Scale factor, examples

Format	Scaling factor ()	Range in Hex (fractional value)
(1.15)	2 ¹⁵ = 32768	$0x7FFF (0.99) \rightarrow 0x8000 (-1)$
(2.14)	2 ¹⁴ = 16384	0x7FFF (1.99) → 0x8000 (-2)
(3.13)	2 ¹³ = 8192	0x7FFF (3.99) → 0x8000 (-4)
(4.12)	2 ¹² = 4096	0x7FFF (7.99) → 0x8000 (-8)
(5.11)	2 ¹¹ = 2048	0x7FFF (15.99) → 0x8000 (-16)
(6.10)	2 ¹⁰ = 1024	0x7FFF (31.99) → 0x8000 (-32)
(7.9)	2 ⁹ = 512	0x7FFF (63.99) → 0x8000 (-64)
(8.8)	2 ⁸ = 256	0x7FFF (127.99) → 0x8000 (-128)
(9.7)	2 ⁷ = 128	0x7FFF (511.99) → 0x8000 (-512)
(10.6)	2 ⁶ = 64	
(11.5)	2 ⁵ = 32	0x7FFF (2047.99) → 0x8000 (–2048)
(12.4)	2 ⁴ = 16	0x7FFF (4095.99) → 0x8000 (–4096)
(13.3)	2 ³ = 8	0x7FFF (4095.99) → 0x8000 (–4096)
(14.2)	2 ² = 4	0x7FFF (8191.99) → 0x8000 (-8192)
(15.1)	21 = 2	0x7FFF (16383.99) → 0x8000 (-16384)
(16.0)	2 ⁰ = 1(Integer)	0x7FFF (32767) → 0x8000h (–32768)

Scale factor

Coder

Scale factor, four-bit signed integer multiplication

Four-Bit Integer Multiplication

Accumulator


11110100

Data Memory

?

Is there another (superior) numbering system?

Scale factor, Q0.3 multiplication



Dynamic range

Dynamic range is defined as,


$$DR_{db} = 20 log_{10} \left(\frac{largest possible word value}{smallest possible word value} \right)$$
 [dB]

For N-bit signed integers,

$$DR_{dB} = 20 \ log_{10} \left[\frac{2^{(N-1)} - 1}{1} \right] \quad [dB]$$
 $DR_{dB} \approx 20 \ [(N-1)log_{10}(2)]$
 $DR_{dB} \approx 20 \ log_{10}(2) \cdot (N-1)$
 $DR_{dB} \approx 6.02 \cdot (N-1) \quad [dB]$

Overflow and underflow

- An overflow occurs in an N-bit 2's complement notation when a result is greater than $2^{N-1} - 1$.
- An overflow produces a roll-over (wrap).
- An **underflow** occurs if a result is less than 2^{-N} .




Addition in 2's complement

- Adding two N-bits numbers can produce a N+1 bits result.
- The last two bits of the carry row show if overflow occurs.

```
11111 111
              (carry)
                           0111
                                    (carry)
 0000 1111
              (15)
                            0111
                                    (7)
 1111 1011
              (-5)
                          + 0011
                                    (3)
              (10)
 0000 1010
                             1010
                                    (-6)
                                          invalid!
```

Overflow

- A roll-over usually has catastrophic consequences on a process.
- Only happen when two very large positive operands, or two very large negative operands are added.
- It can never happen during the addition of a positive operand and a negative operand, whatever their magnitude.



Integers


Longer word-length accumulator

- Saving the result in a N+1 word avoids overflows.
- The general rule is the sum of m individual b-bit can require as many as $b + log_2(m)$.
- Example: 256 8-bits words requires an accumulator whose word length is $8 + log_2(256) = 16$.
- DSP processors usually have 40-bit accumulators.
- ¿How many sums are supported by a 40-bits accumulator for 16-bits numbers?

Saturation

Coder

- To avoid a rollover, overflow is detected and the result is saturated to the most positive or most negative value that can be represented.
- This procedure is called saturation arithmetic.
- DSP processors allows the results to be saturated automatically in hardware (In TI DSP C5505, SATD Bit of ST1 55 register).




Be aware of non-linearity!

Multiplication in 2's complement

- The product of two N-bit numbers requires 2N bits to contain all possible values.
- But the two MSB are always equal (sign extension bit).
- Therefore, 2N-1 bits are enough to store the result.
- A Q15 multiplication produces Q1.30 result.


Fixed-point

- To transform the result into Q31 notation, it must be left-shifted by one bit
- DSP processors have a special mode that allows its ALU to automatically perform the left shift when Q15xQ15.



Logical and Arithmetic shifts

- Multiplication: all bits are shifted left by one position.
- Division: all bits are shifted right by one position, however the sign bit must be preserved (arithmetic shift).
- Arithmetic shift ≠ logical shift.



Logical and Arithmetic shifts (2)

In DSP processors:

- ALU can perform logical shifts of 32-bit operands in one cycle, from 16 bits to the right, to 15 bits to the left.
- Sign extension is performed during shifts to the right, if the Sign Extension Mode control bit (in C5505, SXM) is set.
- Result is saturated during shifts to the left if an overflow is detected, and Overflow bit (in C5505, OVM) is set.

Accumulator

- DSP processors have an accumulator with extra bits to avoid overflow during internal calculations (in C5505, 40-bits accumulator).
- Guard bits: extra bits to avoid addition overflows.
- After MAC operations, only final result is adjusted to memory data size.

b39-b32	b31-b16	b15-b0		
G	Н	L		
Guard bits	High-order bits	Low-order bits		

Integers

How to avoid underflow

Coder

Rounding schemes, truncation and roundoff

- After multiplication, a 2N-bits number must be stored in memory of N-bits word.
- Truncation: e = Q[x] x, $-\Delta \le e < 0$, $\mu = -\frac{\Delta}{2}$, $\sigma^2 = \frac{\Delta}{12}$


$$\mu = -\frac{\Delta}{2}$$
,

$$\sigma^2 = \frac{\Delta}{12}$$

• Roundoff: e = Q[x + 0.5] - x, $-\Delta/2 < e \le \Delta/2$, $\mu = 0$,

$$\mu = 0$$
 ,

DSP processors manage truncation and roundoff automatically.




Number Representation

Coder

Number Representation

A floating-point number can represent a very large or a very small value, positive and negative.



Floating-point Numbers (Decimal)

A floating-point number is typically expressed in the scientific notation in the form of

where,

$$(-1)^{\mathcal{S}} \times F \times r^{\mathcal{E}}$$
,

- S, sign bit.
- F. fraction.
- E, exponent.
- r, certain radix. r = 2 for binary; r = 10 for decimal.

Standards

IEEE Standard P754 Format

Bit 31 30 29 28 27 26 25 24 23 22 21 20
$$\cdots$$
 2 1 0
S 2^7 2^6 2^5 2^4 2^3 2^2 2^1 2^0 2^1 2^2 2^3 \cdots 2^{21} 2^{22} 2^{23}
Sign (s) \leftarrow Exponent (c) \rightarrow \leftarrow Fraction (f) \rightarrow

IBM Format

DEC (Digital Equipment Corp.) Format

Bit 31 30 29 28 27 26 25 24 23 22 21 20
$$\cdots$$
 2 1 0
S | 2⁷ 2⁶ 2⁵ 2⁴ 2³ 2² 2¹ 2⁰ | 2 2 2 3 2 4 \cdots 2 22 2 3 2 4
Sign (s) \leftarrow Exponent (e) \rightarrow \leftarrow Fraction (f) \rightarrow


MIL-STD 1750A Format

Modern computers adopt IEEE 754-2008 standard for representing floating-point numbers.

IEEE 754-2008 standard

IEEE 754-2008 standard defines several formats.

	Binary form	nats (B = 2)			Decimal formats $(B = 10)$			
Parameter	Binary 16	Binary 32	Binary 64	Binary 128	Decimal 132	Decimal 164	Decimal 128	
p, digits	10 + 1	23 + 1	52 + 1	112 + 1	7	16	34	
e_{max}	+15	+127	+1023	+16383	+96	+384	+16,383	
e_{min}	-14	-126	-1022	-16382	-95	-383	-16,382	
Common name	Half precision	Single precision	Double precision	Quadruple precision				




32-bit Single-Precision Floating-point Number

$$(-1)^S \times F \times r^{(E-bias)}$$

- S, sign bit. 0 for positive numbers and 1 for negative numbers.
- E, 8-bits exponent.
- We need to represent both positive and negative exponents.
- E = [1, 254], bias = 127; -126 < E bias < 127.
- E=0 and E=255 are reserved.
- F, 23-bits fraction.

Normalized Form Format

Coder



32-bit Single-Precision Floating-point Number

- Representation of a floating point number may not be unique: $11.01_2 = 1.101_2 \times 2^1 = 110.1_2 \times 2^{-1}$.
- Therefore, the fractional part *F* is normalized.
- 1.F, implicit leading 1.

Normalized Form Example 1

Coder

Represent 3215.020002₁₀

```
Decimal Value Entered: 3215.020002
```

Single precision (32 bits):

```
Binary:
          Status: normal
```

```
Bit 31
                           Bits 30 - 23
                                                                      Bits 22 - 0
Sign Bit
                          Exponent Field
                                                                      Significand
  0
                             100 0101 0
                                                             1 .100 1000 1111 0000 0101 0010
  0: +
          Decimal value of exponent field and exponent | Decimal value of the significand
  1: -
                       138
                             - 127 = 11
                                                                       1.5698340
```

```
Decimal: 3215.0200
Hexadecimal: 4548F052
```

http://babbage.cs.qc.cuny.edu/IEEE-754.old/Decimal.html

Example 2

Represent $3215.020002_{10} \times 2 = 6430.040004_{10}$

Decimal Value Entered: 6430.040004

Single precision (32 bits):

Binary: Status: normal

Bit 31
Sign Bit

O

Decimal value of exponent field and exponent line

139 - 127 = 12

Bits 22 - 0 Significand 1.10010001111000001010010 Decimal value of the significand

1.5698340

Hexadecimal: 45C8F052 Decimal: 6430.0400

Normalized Form Example 3

Coder

Represent $3215.020002_{10}/4 = 803.7550005_{10}$

Decimal Value Entered: 803.7550005

Single precision (32 bits):

```
Status: normal
Binary:
  Bit 31
                           Bits 30 - 23
                                                                      Bits 22 - 0
Sign Bit
                          Exponent Field
                                                                      Significand
   0
                             10001000
                                                             1 .10010001111000001010010
                                                           Decimal value of the significand
          Decimal value of exponent field and exponent
   1: -
                              -127 = 9
                        136
                                                                      1.5698340
```

Hexadecimal: 4448F052 Decimal: 803.75500

Floating-point numbers are auto-scaled!.


De-normalized Form **Format**

Coder

Not all real numbers in the range are representable

 $-N_{min}$ $+N_{min}$ $-N_{max}$ $+N_{max}$

Normalized floating-point numbers



Denormalized floating-point numbers

- Normalized form has a serious problem, with an implicit leading 1 for the fraction, it cannot represent the number zero!
- De-normalized form was devised to represent zero and small numbers.
- $E = 0 \Rightarrow 0.F$, implicit leading 0.

De-normalized Form Example

Coder

Represent -3.4E-39₁₀

Decimal Value Entered: -3.4e-39

Single precision (32 bits):

Binary: Status: denormalized

Bit 31 Bits 30 - 23 Sign Bit Exponent Field 1 00000000 0: + Decimal value of exponent field and exponent 1: -0 - 127 = -127

Bits 22 - 0 Significand 0.1001010000010111010001 Decimal value of the significand

0.5784800

Hexadecimal: 802505D1 Decimal: -3.3999999e-39 De-normalized Form

Coder

Special values

- **Zero**: E=0, F=0. Two representations: +0 (S=0) and -0 (S=1).
- Inf (Infinity): E = 0xFF, F = 0. Two representations: +Inf (S = 0) and -Inf (S = 1).
- NaN (Not a Number): E = 0xFF, $F \neq 0$. A value that cannot be represented as a real number (e.g. 0/0).

MATLAB

- $\mathbf{0}$ » a = 1/0
- » ans = Inf
- \bigcirc » b = -1/0
- \bigcirc » c = 0/0
- » ans = NaN

Rounding schemes

Rounding schemes

- ulp (unit of least precision, eps ()).
- f, significant, f = 1.F.
- f' and f'' being two successive multiples of ulp.
- Assume that f' < f < f'', f'' = f' + ulp.
- Then, the rounding function round(f) associates to f either f' or f'', according to some rounding strategy.

Rounding schemes are:

- Truncation (also called round toward 0 or chopping): round(s) = f' if f is positive, round(-f) = f'' if f is negative.
- Round toward plus infinity: round(s) = f"
- Round toward minus infinity: round(s) = f'
- Round to nearest (default): if f < f' + ulp/2, round(f) = f', and if f > f' + ulp/2, round(f) = f''.

Dynamic range

Coder

Dynamic range

$$DR_{dB} \approx 6.02 \cdot 2^{b_E}$$

where b_E is the number of bits of E.

For single precision (32-bits):

$$DR_{dB} \approx 6.02 \cdot 2^8 \approx 1541 \, dB$$

For fixed-point Q31 (32-bits):

$$DR_{dB} \approx 6.02 \cdot 31 \approx 186 \, \mathrm{dB}$$


Precision

- Precision is not constant throughout floating point numbers' range.
- As the numbers get larger, the precision gets worse.


MATLAB

- \bullet w u = linspace (-15, 15, 1000);
- ② » q = quantizer([6 4],'float'); % [wordlength exponentlength]
- \bigcirc » y1 = quantize(q,u);
- **6** »
- y q = quantizer('fixed', [6 2]); % [wordlength fractionlength]
- \bigcirc » y2 = quantize(q,u);
- 3 » plot(u,y2); title(tostring(q))

Precision (2)







Precision (4)

 $\mathtt{eps}\,(\mathtt{x})$ returns the positive distance from $\mathtt{abs}\,(\mathtt{x})$ to the next larger in magnitude floating point number of the same precision.

MATLAB

- \bigcirc » e1 = eps(single(1))
- ② » e1 = 1.1920929e-07
- \odot » e2 = eps(single(1e1))
- 4 » e2 = 9.5367432e-07
- \bullet » e3 = eps(single(1e10))
- \bullet » e3 = 1024

Sum of two floating-point positive numbers

$$n = n_1 + n_2 = 1.F \times r^{(E-bias)},$$

 $n_1 = 1.F_1 \times r^{(E_1-bias)},$
 $n_2 = 1.F_2 \times r^{(E_2-bias)}.$

• if $E_1 >= E_2$ then.

$$E = E_1, F = F_1 + (F_2 >> (E_1 - E_2))$$

else.

$$E = E_2, F = (F_1 >> (E_2 - E_1)) + F_2$$

• if F >= r then. (first normalization)

$$E = E + 1, F = F >> 1$$

- \bullet F = round(F)
- if F >= r then. (second normalization)

$$E = E + 1$$
. $F = F >> 1$

Example 1

Coder

• if
$$160 >= 131$$
 then,

$$E = 160.$$

$$E = 160, F = 1.001010100000010111111001$$

$$n = (-1)^0 \times 1.001010100000010111111001 \times r^{(160-127)}$$

Example 2


Coder

- In floating-point processors scaling the data increases dynamic range, but scaling does not improve precision, and in fact degrades performance.
- When calculations involve large and small numbers at the same time, the loss of precision affects the small number and the result.

MATLAB

- \bigcirc » $(2^53 + 1) 2^53$
- 0 > x=1, t = tan(x) sin(x)/cos(x)
- \bigcirc » t = 2.2204e-16 % eps(1)

Fixed-point vs floating-point



Bibliography

Coder

- Bruno Paillard. An Introduction To Digital Signal Processors, Chapter 5 "Binary representations and fixed-point arithmetic".
- Richard G. Lyons. Understanding Digital Signal, Chapter 12 "Digital data formats and their effects".
- Texas Instruments. C28x IQ Math Library. Link to document.
- Jean-Pierre Deschamps, Gustavo D. Sutter, and Enrique Cantó. Guide to FPGA Implementation of Arithmetic Functions, Chapter 12 "Floating Point Arithmetic".