# Finite representation of real numbers Fixed-point numbers

Dr. Ing. Rodrigo Gonzalez

rodralez@frm.utn.edu.ar


Técnicas Digitales III



### Summary

- Finite representation of real numbers in computers
- Integers
- Fixed-point
  - Scale factor
  - Dynamic range
  - How to determine the correct integer value (m)
- Addition
  - Overflow
  - How to avoid overflow
- Multiplication
  - Underflow
  - How to avoid underflow
- MAC operation
- **Shifts**

### Gangnam Style problem



#### https://arstechnica.com

Shifts

# Patriot Missile System problem

- On February 25th, 1991, a Patriot Missile system at Dhahran, Saudi Arabia failed to intercept a SCUD missile, killing 28 Americans soldiers.
- The radar of a Patriot missile system is designed to detect an incoming missile twice in order to avoid false alarms.
- Time is stored to an accuracy of 1/10th of a second in a 24-bit register.
- It results in 0.000111101110011001100110011001101... with an infinite number of bits.



- The error of representing 1/10th s in 24-bit register is 0.000000095 decimal of seconds (000000000000000000000110011001...).
- $\bullet$  After 100 hours of operation, cumulative error gives 0.000000095  $\times 100 \times 60 \times 60 \times 10 = 0.34$  s.
- A SCUD travels at about 1,676 m/s. In 0.34 s, it travels more than half a kilometer.
- This error in the time calculation caused the Patriot system to expect an incoming missile at a wrong location for the second detection, causing it to consider the first detection as false alarm.

More information at https://blog.penjee.com/famous-number-computing-errors/

### Integers

### Unsigned integers

- An N-bit binary word can represent a total of 2<sup>N</sup> separate values.
- Range: 0 to 2<sup>N</sup> − 1

Finite representation of real numbers in computers

• 
$$n_{10} = 2^{N-1}b_{N-1} + 2^{N-2}b_{N-2} + \dots + 2^{1}b_{1} + 2^{0}b_{0}$$

### 2's complement signed integers

• Range: 
$$-2^{N-1}$$
 to  $2^{N-1} - 1$ .

• 
$$n_{10} = -b_{N-1}2^{N-1} + \sum_{i=0}^{N-2} b_i 2^i$$

#### in C:

•	8 bits	(char,	int8_	_t):	[-128,	127]]
---	--------	--------	-------	------	--------	-------

- 16 bits (short, int16\_t): [-32768, 32767]
- 32 bits (int, long, int32\_t): [-2147483648, 2147483647]

Bit Pattern	Unsigned	2's Complemen
0000 0000	0	0
0000 0001	1	1
0000 0010	2	2
•	•	•
•	•	•
0111 1110	126	126
0111 1111	127	127
1000 0000	128	-128
1000 0001	129	-127
•	•	•
•	•	•
1111 1110	254	-2
1111 1111	255	-1


# Fixed-point representation

In fixed-point representation, a real number x is represented by an integer X with N=m+n+1 bits, where:

- N is the wordlength.
- m represents the number of integer bits (to the left of the binary point).
- n represents the number of fractional bits (to the right of the binary point).
- The weights of bits to the right of the binary point are negative powers of 2:  $2^{-1} = \frac{1}{2}$ ,  $2^{-2} = \frac{1}{4}$  ..., etc.

• 
$$n_{10} = (-1^{2^m}) \left( \sum_{i=0}^{m-1} b_i 2^i + \sum_{i=1}^n b_i 2^{-i} \right)$$

- Precision: 2<sup>−n</sup>.
- Range: −2<sup>m</sup> to 2<sup>m</sup> − 2<sup>-n</sup>.
- What happens if n = 0?



8-bit field

### Qm.n notation

Finite representation of real numbers in computers

This naming convention does not take the MSB of the number (sign bit) into account.

#### For instance:

- Q0.15 (Q15)
  - 16 bits;
  - Range: -1 to 0.99996948;
  - Precision: 1/32768 (2<sup>-15</sup>).
- Q3.12
  - 16 bits;
  - Range: -8 to 7.9998;
  - Precision: 1/4096 (2<sup>-12</sup>).
- Q0.31 (Q31)
  - 32 bits;
  - Range: -1 to 0.999999999534339;
  - Precision: 4.6566129e-10 (2<sup>-31</sup>).

# Conversion to and from fixed point

Defining:

• Unit: 
$$z = 1 << n = 1 \cdot 2^n$$

• One half: 
$$z = 1 << (n-1) = 1 \cdot 2^{(n-1)}$$

Conversion from floating-point ("real") to fixed-point number:

$$X := (int)(x \cdot (1 << n))$$

$$X := (int)(x \cdot 2^n)$$

(2)

(1)

Conversion from fixed-point to floating-point ("real") number:

$$x := \frac{(float)(X)}{(1 << n)}$$

$$x := (float)(X) \cdot 2^{-n}$$

**Example 1:** Represent x = 13.4 using Q4.3 format

$$X = round(13.4 \cdot 2^3) = 107 (01101011_2)$$

**Example 2:** Represent x = 0.052246 using Q4.11 format

$$X = round(0.052246 \cdot 2^{11}) = 107 (000000001101011_2)$$

Rodrigo Gonzalez (TD III, UTN-FRM)

#### Scale factor

# Scale of representation

Finite representation of real numbers in computers

- There is no difference at the CPU level (ALU) between both fixed-point and integer numbers.
- The difference is based on the concept of scale, which is almost completely in the head of the designer.
- Values represented in Qm.n notation can be seen as a signed integer simply multiplied by  $2^{-n}$ , the precision.
- In fact, the scale factor can be an arbitrary scale that is not a power of two.
- Example: 16-bit 2's complement numbers between 8000H and 7FFFH can represent decimal values between -5 and +5, where the scale factor is 5/32768 (5 \*  $2^{-15}$ ).
  - Integer: -32768 to 32767 (8000H 7FFFH).
  - 2 Fixed point Q15:  $(-32768 * 2^{-15})$  to  $(32767 * 2^{-15}) = > -1$  to 0.99996948242.
  - (-1\*5) to (0.99996948242\*5) => -5 to 4.99984741211.

Scale factor

# Scale factor, examples

Format	Scaling factor ( )	Range in Hex (fractional value)
(1.15)	2 <sup>15</sup> = 32768	0x7FFF (0.99) → 0x8000 (-1)
(2.14)	2 <sup>14</sup> = 16384	0x7FFF (1.99) → 0x8000 (-2)
(3.13)	2 <sup>13</sup> = 8192	0x7FFF (3.99) → 0x8000 (-4)
(4.12)	2 <sup>12</sup> = 4096	0x7FFF (7.99) → 0x8000 (-8)
(5.11)	2 <sup>11</sup> = 2048	0x7FFF (15.99) → 0x8000 (-16)
(6.10)	2 <sup>10</sup> = 1024	0x7FFF (31.99) → 0x8000 (-32)
(7.9)	2 <sup>9</sup> = 512	0x7FFF (63.99) → 0x8000 (-64)
(8.8)	2 <sup>8</sup> = 256	0x7FFF (127.99) → 0x8000 (–128)
(9.7)	2 <sup>7</sup> = 128	0x7FFF (511.99) → 0x8000 (-512)
(10.6)	2 <sup>6</sup> = 64	0x7FFF (1023.99) → 0x8000 (-1024)
(11.5)	2 <sup>5</sup> = 32	0x7FFF (2047.99) → 0x8000 (–2048)
(12.4)	2 <sup>4</sup> = 16	0x7FFF (4095.99) → 0x8000 (-4096)
(13.3)	2 <sup>3</sup> = 8	0x7FFF (4095.99) → 0x8000 (-4096)
(14.2)	2 <sup>2</sup> = 4	0x7FFF (8191.99) → 0x8000 (-8192)
(15.1)	21 = 2	0x7FFF (16383.99) → 0x8000 (-16384)
(16.0)	2 <sup>0</sup> = 1(Integer)	0x7FFF (32767) → 0x8000h (-32768)

Finite representation of real numbers in computers

Dynamic range

# Dynamic range

Dynamic range is defined as,

$$DR_{db} = 20 log_{10} \left( \frac{\text{largest possible word value}}{\text{smallest possible word value}} \right) [dB]$$

For N-bit signed integers.

$$DR_{dB} = 20 \ log_{10} \left[ \frac{2^{(N-1)} - 1}{1} \right] \quad [dB]$$
 $DR_{dB} \approx 20 \ [(N-1)log_{10}(2)]$ 
 $DR_{dB} \approx 20 \ log_{10}(2) \cdot (N-1)$ 
 $DR_{dB} \approx 6.02 \cdot (N-1) \quad [dB]$ 

Dynamic range

# Precision and Dynamic range examples

Format	(N.M)	Largest positive value (0x7FFF)	Least negative value (0x8000)	Precision	(0x0001)	DR(dB)
1	15	0,999969482421875	-1	3,05176E-05	2^-15	90,30873362
2	14	1,99993896484375	-2	6,10352E-05	2^-14	90,30873362
3	13	3,9998779296875	-4	0,00012207	2^-13	90,30873362
4	12	7,999755859375	-8	0,000244141	2^-12	90,30873362
5	11	15,99951171875	-16	0,000488281	2^-11	90,30873362
6	10	31,99902344	-32	0,000976563	2^-10	90,30873362
7	9	63,99804688	-64	0,001953125	2^-9	90,30873362
8	8	127,9960938	-128	0,00390625	2^-8	90,30873362
9	7	255,9921875	-256	0,0078125	2^-7	90,30873362
10	6	511,984375	-512	0,015625	2^-6	90,30873362
11	5	1023,96875	-1024	0,03125	2^-5	90,30873362
12	4	2047,9375	-2048	0,0625	2^-4	90,30873362
13	3	4095,875	-4096	0,125	2^-3	90,30873362
14	2	8191,75	-8192	0,25	2^-2	90,30873362
15	1	16383,5	-16384	0,5	2^-1	90,30873362
16	0	32767	-32768	1	2^-0	90,30873362

Finite representation of real numbers in computers How to determine the correct integer value (m)

# How to determine the correct integer value (*m*)

What is the correct value for m?

How much bits are needed to represent -15 < x < 10?

#### **MATLAB**

- N INT MIN = abs(-15); INT MAX = 10;
- MAX = max( [ INT\_MIN, INT\_MAX ] ); % MAX = 15
- $\bigcirc$  >> BITS = (log2 ( MAX ) + 2 );
- N = floor (BITS); % floor() rounds to -Inf
- $\odot$  » N = 5.00

# Addition in 2's complement


Finite representation of real numbers in computers

- Adding two N-bits numbers can produce a N+1 bits result.
- The result will have the same numbers of fractional bits.
- Only the integer part can grow.
- The last two bits of the carry row show if overflow occurs.

```
11111 111
             (carry)
                           0111
                                   (carry)
 0000 1111
             (15)
                            0111
                                   (7)
1111 1011
             (-5)
                          + 0011
                                   (3)
 0000 1010
             (10)
                            1010
                                   (-6)
                                          invalid!
```

# Overflow


- An **overflow** occurs in a when a result is greater than  $2^{N-1} 1$  or lesser than  $-2^{N-1}$ .
- An overflow produces a roll-over (wrap).



# Overflow II

Overflow

- A roll-over usually has catastrophic consequences on a process.
- It only happens when two very large positive operands, or two very large negative operands, are added.
- It can never happen during the addition of a positive operand and a negative operand, whatever their magnitude.



How to avoid overflow


# Longer word-length accumulator

- Saving the result in a N+1 word avoids overflows.
- The general rule is the sum of s individual m-bit can require as many as  $m + log_2(s)$ .
- Example: 256 8-bits words requires an accumulator whose word length is  $8 + log_2(256) = 16.$
- DSP processors usually have 40-bit accumulators.
- How many sums are supported by a 40-bits accumulator for 16-bits numbers?

How to avoid overflow

### Saturation

- To avoid a rollover, overflow is detected and the result is saturated to the most positive or most negative value that can be represented.
- This procedure is called **saturation arithmetic**.
- DSP processors allows the results to be saturated automatically in hardware (In TI DSP C5505, SATD Bit at ST1\_55 register).




Be aware of non-linearity!

### Multiplication in 2's complement

Finite representation of real numbers in computers


- The product of 2 N-bit numbers requires 2 · N bits bits to contain all possible values.
- The 2 Most Significant Bits (MSB) are always equal (extension sign bit).
- Therefore, 2N-1 bits are enough to store the result.
- A Q15 multiplication produces Q1.30 result.
- To transform the result into Q31 notation, it must be left-shifted by one bit.
- DSP processors have a special mode that allows its ALU to automatically perform the left shift when Q15xQ15.



# Four-bit signed integer multiplication


# **Four-Bit Integer Multiplication** 0100 x 1101 00000100 0000000 000100 11100 -12 11110100 -12 Accumulator 11110100 11110100 **Data Memory**

### Four-bit Q0.3 multiplication



### Underflow Underflow

- After multiplication, 2N-1 bits must be stored in a memory of N-bits word.
- An **underflow** occurs if the result is less than  $2^{-n}$ .
- Example: Q0.3 precision is  $2^{-3} = \frac{1}{\alpha}$ .



- What number should the multiplication result be? -1/8 or -2/8?
- In other words, what bits should be discarded from a multiplication result?

# Rounding schemes, truncation and round-off


#### Truncation

- $\bullet$  y=Q(x).
- floor() function in MATLAB, also known as round to minus infinity.

#### Round-off

• 
$$y = Q(x + 2^{-(n+1)})$$


• round () function in MATLAB, also known as round to the nearest.



# Error in rounding schemes

Error in rounding schemes is modeled as a uniform probability distribution.

mean, 
$$\mu=\frac{a+b}{2}$$
 variance,  $\sigma^2=\frac{(b-a)^2}{12}$ 



• Truncation: e = Q(x) - x,  $-2^{-n} \le e < 0$ ,  $\mu = -\frac{2^{-n}}{2}$ ,  $\sigma^2 = \frac{2^{-n}}{12}$ 

$$\mu = -\frac{2^{-n}}{2}, \quad \sigma^2 = \frac{2^{-n}}{12}$$

- Round-off:  $e = Q(x + 2^{-(n+1)}) x$ ,  $-2^{-n}/2 < e \le 2^{-n}/2$ ,  $\mu = 0$ ,  $\sigma^2 = \frac{2^{-n}}{12}$ .
- What is  $2^{-(n+1)}$ ?
- DSP processors manage truncation and round-off automatically.

### MAC operation

- MAC stands for Multiply and ACcumulate.
- Since it represents the convolution operation, it is THE basic arithmetic operation in DSP.

#### In C:

#### C code

- 0 c = 0:
- for (i=0; i=N; i++) {
- 0 c = c + (a \* b); };
- A MAC operation summarizes the addition and multiplication problems, i.e., overflows and underflows.
- DSP processors have an accumulator with extra bits (guard bits) to avoid overflow during internal calculations (in TI DSP C5505, 40-bits accumulator).


b39-b32	b31-b16	b15-b0
G	Н	L

Guard bits High-order bits Low-order bits

# Logical and Arithmetic shifts

Finite representation of real numbers in computers

- Multiplication by 2: all bits are shifted left by one position.
- Division by 2: all bits are shifted right by one position (logical shift).
- What happens with 2-complement numbers?
- The sign bit must be preserved! (arithmetic shift).
- Arithmetic shift ≠ logical shift.



Shifts

# Logical and Arithmetic shifts II

#### In DSP processors:

- ALU can perform logical shifts of 32-bit operands in one cycle, from 16 bits to the right, to 15 bits to the left.
- Sign extension is performed during shifts to the right, if the Sign Extension Mode control bit (in C5505, SXM) is set.
- Result is saturated during shifts to the left if an overflow is detected, and Overflow bit (in C5505, OVM) is set.

# Bibliography

- Richard G. Lyons. *Understanding Digital Signal Processing, 3rd Ed.* Prentice Hill. 2010. Chapter 12.
- 2 Bruno Paillard. An Introduction To Digital Signal Processors, Chapter 5.