Fuse

Screw1 100nF 100nF 100mF 100mF P-50uH/50uH LTSP_25-NP 4.7uF CI2 CI3 Screw2 P+ Cc2 Cc4 Cc3 Col Screw3 В-| | | LM7812_T0220 C02 C03 Co1 DRIVER_(INEP) Screw4 B+

SCS