Лабораторная работа №7. Взаимодействие с драйверами устройств

Взаимодействие с модулями ядра — драйверами

Если требуется обеспечить настройку и работу устройства, необходимо не только написать драйвер устройства — модуль ядра — но и обеспечить возможность настраивать это устройство через него.

Интересным и практичным примером может также служить случай, когда необходимо получать данные с физических адресов данных, а не с виртуальных. Например, если микропроцессорная система имеет доступ к системной памяти устройства, в которое она встроена. Разумеется, это можно проводить только в пространстве ядра.

Для задания поддерживаемых драйвером операций нужно описать экземпляр структуры file operations.

```
struct file operations {
        struct module *owner;
         loff t(*llseek) (struct file *, loff t, int);
         ssize_t(*read) (struct file *, char __user *, size_t, loff_t *);
         ssize_t(*aio_read) (struct kiocb *, char __user *, size_t, loff_t);
         ssize t(*write) (struct file *, const char user *, size t, loff t *);
        ssize t(*aio write) (struct kiocb *, const char user *, size t,
                              loff t);
        int (*readdir) (struct file *, void *, filldir t);
        unsigned int (*poll) (struct file *, struct poll table struct *);
        int (*ioctl) (struct inode *, struct file *, unsigned int,
                      unsigned long);
       int (*mmap) (struct file *, struct vm area struct *);
       int (*open) (struct inode *, struct file *);
        int (*flush) (struct file *);
       int (*release) (struct inode *, struct file *);
       int (*fsync) (struct file *, struct dentry *, int datasync);
        int (*aio fsync) (struct kiocb *, int datasync);
        int (*fasync) (int, struct file *, int);
        int (*lock) (struct file *, int, struct file lock *);
         ssize t(*readv) (struct file *, const struct iovec *, unsigned long,
                          loff t *);
         ssize t(*writev) (struct file *, const struct iovec *, unsigned long,
                           loff t *);
         ssize t(*sendfile) (struct file *, loff t *, size t, read actor t,
         void __user *);
ssize_t(*sendpage) (struct file *, struct page *, int, size_t,
                             loff t *, int);
        unsigned long (*get unmapped area) (struct file *, unsigned long,
                                            unsigned long, unsigned long,
                                            unsigned long);
};
```

Основными функциями часто выступают: открытие, закрытие, чтение, запись.

Взаимодействие через файл устройства

Зарегистрировав драйвер в системе и получив для него старший номер, можно создавать файлы устройств, которые будут работать под управлением этого

драйвера.

Так, записывая что-то в файл (например, echo "command value" > /dev/chardev) или копируя из него, можно взаимодействовать с драйвером. Для этого он должен проводить анализ и определять, какие команды ему передаются.

Пример подобного драйвера приведён ниже.

```
chardev.c: Creates a read-only char device that says how many times
   you've read from the dev file
#include <linux/kernel.h>
#include <linux/module.h>
#include <linux/fs.h>
                           /* for put user */
#include <asm/uaccess.h>
  Prototypes - this would normally go in a .h file
* /
int init_module(void);
void cleanup module(void);
static int device open(struct inode *, struct file *);
static int device release(struct inode *, struct file *);
static ssize t device read(struct file *, char *, size_t, loff_t *);
static ssize t device write(struct file *, const char *, size t, loff t *);
#define SUCCESS 0
#define DEVICE NAME "chardev" /* Dev name as it appears in /proc/devices
                                                                             */
#define BUF LEN 80
                              /* Max length of the message from the device */
* Global variables are declared as static, so are global within the file.
static int Major;
                               /* Major number assigned to our device driver
static int Device Open = 0;
                              /* Is device open?
                                * Used to prevent multiple access to device */
static char msg[BUF LEN];
                              /* The msg the device will give when asked */
static char *msg Ptr;
static struct file operations fops = {
       .read = device read,
       .write = device write,
       .open = device open,
       .release = device release
};
* This function is called when the module is loaded
int init module(void)
{
       Major = register chrdev(0, DEVICE NAME, &fops);
        if (Major < 0) {
         printk(KERN ALERT "Registering char device failed with %d\n", Major);
         return Major;
       printk(KERN INFO "I was assigned major number %d. To talk to\n",
Major);
```

```
printk(KERN INFO "the driver, create a dev file with\n");
        printk(KERN INFO "'mknod /dev/%s c %d 0'.\n", DEVICE NAME, Major);
        printk(KERN INFO "Try various minor numbers. Try to cat and echo
to\n");
        printk(KERN INFO "the device file.\n");
        printk(KERN INFO "Remove the device file and module when done.\n");
        return SUCCESS;
}
* This function is called when the module is unloaded
void cleanup_module(void)
        /*
        * Unregister the device
        int ret = unregister chrdev(Major, DEVICE NAME);
        if (ret < 0)
                printk(KERN ALERT "Error in unregister_chrdev: %d\n", ret);
}
/*
* Methods
/*
* Called when a process tries to open the device file, like
* "cat /dev/mycharfile"
static int device open(struct inode *inode, struct file *file)
        static int counter = 0;
        if (Device_Open)
               return -EBUSY;
       Device Open++;
       sprintf(msg, "I already told you %d times Hello world!\n", counter++);
       msg Ptr = msg;
       try_module_get(THIS_MODULE);
       return SUCCESS;
}
* Called when a process closes the device file.
static int device release(struct inode *inode, struct file *file)
        Device Open--;
                               /* We're now ready for our next caller */
        * Decrement the usage count, or else once you opened the file, you'll
        * never get get rid of the module.
        module_put(THIS_MODULE);
       return 0;
```

```
* Called when a process, which already opened the dev file, attempts to
 * read from it.
*/
static ssize_t device_read(struct file *filp, /* see include/linux/fs.h
                                                                            * /
                           char *buffer,
                                               /* buffer to fill with data */
                                               /* length of the buffer
                           size t length,
                           loff t * offset)
{
        * Number of bytes actually written to the buffer
       int bytes_read = 0;
        /*
        * If we're at the end of the message,
        * return 0 signifying end of file
        if (*msg Ptr == 0)
               return 0;
         * Actually put the data into the buffer
       while (length && *msg Ptr) {
                * The buffer is in the user data segment, not the kernel
                 * segment so "*" assignment won't work. We have to use
                 * put user which copies data from the kernel data segment to
                 * the user data segment.
                put user(*(msg Ptr++), buffer++);
                length--;
               bytes_read++;
        }
        * Most read functions return the number of bytes put into the buffer
       return bytes read;
}
* Called when a process writes to dev file: echo "hi" > /dev/hello
static ssize t
device write(struct file *filp, const char *buff, size t len, loff t * off)
       printk(KERN ALERT "Sorry, this operation isn't supported.\n");
       return -EINVAL;
```

Взаимодействие через процесс

Если необходимо обеспечивать контроль ввода/вывода устройства через процесс, то создаётся набор специальных функций IOCTL (Input Output Control). Благодаря им можно более тонко управлять процессом ввода и вывода, например, читая только какой-то определённый байт из устройства.

Также это позволяет взаимодействовать с драйвером из любого процесса, а не через

командную строку.

Простейший пример подобной организации ввода/вывода приведён ниже. Заголовочный файл нужно включать как в исходный код самого модуля, так и в исходный код процесса.

```
* chardev.c - Create an input/output character device
#include <linux/kernel.h>
                              /* We're doing kernel work */
#include <linux/module.h>
                               /* Specifically, a module */
#include <linux/fs.h>
#include <asm/uaccess.h>
                              /* for get user and put user */
#include "chardev.h"
#define SUCCESS 0
#define DEVICE NAME "char dev"
#define BUF LEN 80
* Is the device open right now? Used to prevent
* concurent access into the same device
static int Device Open = 0;
* The message the device will give when asked
static char Message[BUF LEN];
/*
* How far did the process reading the message get?
* Useful if the message is larger than the size of the
* buffer we get to fill in device read.
static char *Message_Ptr;
* This is called whenever a process attempts to open the device file
static int device open(struct inode *inode, struct file *file)
#ifdef DEBUG
       printk(KERN_INFO "device_open(%p)\n", file);
#endif
        * We don't want to talk to two processes at the same time
        */
        if (Device Open)
               return -EBUSY;
       Device Open++;
        * Initialize the message
        * /
       Message Ptr = Message;
       try module get (THIS MODULE);
       return SUCCESS;
}
static int device release(struct inode *inode, struct file *file)
```

```
#ifdef DEBUG
       printk(KERN INFO "device release(%p,%p)\n", inode, file);
#endif
        * We're now ready for our next caller
       Device_Open--;
        module put (THIS MODULE);
        return SUCCESS;
^{\star} This function is called whenever a process which has already opened the
* device file attempts to read from it.
static ssize t device read(struct file *file, /* see include/linux/fs.h */
                           char user * buffer,
                                                        /* buffer to be
                                                         * filled with data */
                                               /* length of the buffer */
                           size t length,
                           loff t * offset)
{
        * Number of bytes actually written to the buffer
        int bytes read = 0;
#ifdef DEBUG
       printk(KERN INFO "device read(%p,%p,%d)\n", file, buffer, length);
#endif
        * If we're at the end of the message, return 0
        * (which signifies end of file)
        if (*Message Ptr == 0)
               return 0;
        * Actually put the data into the buffer
        while (length && *Message Ptr) {
                * Because the buffer is in the user data segment,
                 * not the kernel data segment, assignment wouldn't
                 * work. Instead, we have to use put user which
                 * copies data from the kernel data segment to the
                 * user data segment.
                 */
                put user(*(Message Ptr++), buffer++);
                length--;
               bytes read++;
        }
       printk(KERN INFO "Read %d bytes, %d left\n", bytes read, length);
#endif
        ^{\star} Read functions are supposed to return the number
         * of bytes actually inserted into the buffer
```

```
return bytes read;
/*
* This function is called when somebody tries to
* write into our device file.
* /
static ssize t
device write(struct file *file,
             const char user * buffer, size t length, loff t * offset)
{
       int i;
#ifdef DEBUG
       printk(KERN INFO "device write(%p,%s,%d)", file, buffer, length);
#endif
       for (i = 0; i < length && i < BUF LEN; i++)
               get user(Message[i], buffer + i);
       Message_Ptr = Message;
        * Again, return the number of input characters used
       return i;
/*
* This function is called whenever a process tries to do an ioctl on our
* device file. We get two extra parameters (additional to the inode and file
* structures, which all device functions get): the number of the ioctl called
 * and the parameter given to the ioctl function.
* If the ioctl is write or read/write (meaning output is returned to the
* calling process), the ioctl call returns the output of this function.
*/
int device ioctl(struct inode *inode, /* see include/linux/fs.h */
                struct file *file, /* ditto */
                unsigned int ioctl num,
                                           /* number and param for ioctl
*/
                unsigned long ioctl param)
{
       int i;
       char *temp;
       char ch;
        * Switch according to the ioctl called
        * /
       switch (ioctl num) {
        case IOCTL SET MSG:
                /*
                ^{\star} Receive a pointer to a message (in user space) and set that
                * to be the device's message. Get the parameter given to
                 * ioctl by the process.
                 */
                temp = (char *)ioctl param;
                 * Find the length of the message
```

```
* /
               get user(ch, temp);
               for (i = 0; ch \&\& i < BUF LEN; i++, temp++)
                       get user(ch, temp);
               device write(file, (char *)ioctl param, i, 0);
               break;
       case IOCTL GET MSG:
                * Give the current message to the calling process -
                * the parameter we got is a pointer, fill it.
               i = device_read(file, (char *)ioctl_param, 99, 0);
               /*
                ^{\star} Put a zero at the end of the buffer, so it will be
                * properly terminated
               put user('\0', (char *)ioctl param + i);
               break;
       case IOCTL_GET_NTH BYTE:
               /*
                * This ioctl is both input (ioctl_param) and
                * output (the return value of this function)
               return Message[ioctl param];
               break;
       return SUCCESS;
/* Module Declarations */
* This structure will hold the functions to be called
^{\star} when a process does something to the device we
* created. Since a pointer to this structure is kept in
* the devices table, it can't be local to
* init module. NULL is for unimplemented functions.
*/
struct file_operations Fops = {
       .read = device read,
       .write = device write,
       .ioctl = device ioctl,
       .open = device open,
       };
* Initialize the module - Register the character device
int init module()
{
       int ret val;
        * Register the character device (atleast try)
       ret val = register chrdev(MAJOR NUM, DEVICE NAME, &Fops);
```

```
* Negative values signify an error
         */
        if (ret val < 0) {
                printk(KERN ALERT "%s failed with %d\n",
                       "Sorry, registering the character device ", ret val);
                return ret val;
        printk(KERN INFO "%s The major device number is %d.\n",
               "Registeration is a success", MAJOR NUM);
        printk(KERN INFO "If you want to talk to the device driver, \n");
        printk(KERN INFO "you'll have to create a device file. \n");
        printk(KERN INFO "We suggest you use:\n");
       printk(KERN INFO "mknod %s c %d 0\n", DEVICE_FILE_NAME, MAJOR_NUM);
       printk(KERN INFO "The device file name is important, because\n");
        printk(KERN INFO "the ioctl program assumes that's the\n");
       printk(KERN INFO "file you'll use.\n");
       return 0;
* Cleanup - unregister the appropriate file from /proc
void cleanup module()
        int ret;
        * Unregister the device
        ret = unregister chrdev(MAJOR NUM, DEVICE NAME);
        * If there's an error, report it
        if (ret < 0)
                printk(KERN ALERT "Error: unregister chrdev: %d\n", ret);
```

```
* chardev.h - the header file with the ioctl definitions.

*
    The declarations here have to be in a header file, because
    they need to be known both to the kernel module
    (in chardev.c) and the process calling ioctl (ioctl.c)

*/

#ifndef CHARDEV_H
#define CHARDEV_H
#include <linux/ioctl.h>

/*
    * The major device number. We can't rely on dynamic
    * registration any more, because ioctls need to know
    it.
    */
#define MAJOR_NUM 100

/*
    * Set the message of the device driver
```

```
#define IOCTL SET MSG IOR(MAJOR NUM, 0, char *)
   IOR means that we're creating an ioctl command
^{\star} number for passing information from a user process
* to the kernel module.
^{\star} The first arguments, MAJOR NUM, is the major device
* number we're using.
* The second argument is the number of the command
^{\star} (there could be several with different meanings).
^{\star} The third argument is the type we want to get from
^{\star} the process to the kernel.
/*
* Get the message of the device driver
#define IOCTL GET MSG IOR(MAJOR NUM, 1, char *)
^{\star} This IOCTL is used for output, to get the message
* of the device driver. However, we still need the
* buffer to place the message in to be input,
^{\star} as it is allocated by the process.
*/
* Get the n'th byte of the message
#define IOCTL GET NTH BYTE IOWR(MAJOR NUM, 2, int)
* The IOCTL is used for both input and output. It
* receives from the user a number, n, and returns
* Message[n].
*/
* The name of the device file
#define DEVICE FILE NAME "char dev"
#endif
```

```
/*
 * ioctl.c - the process to use ioctl's to control the kernel module

* Until now we could have used cat for input and output. But now
 * we need to do ioctl's, which require writing our own process.

*/

/*
 * device specifics, such as ioctl numbers and the
 * major device file.
 */
#include "chardev.h"

#include <stdio.h>
#include <stdlib.h>
#include <fcntl.h> /* open */
```

```
/* exit */
#include <unistd.h>
#include <sys/ioctl.h>
                               /* ioctl */
* Functions for the ioctl calls
ioctl set msg(int file desc, char *message)
        int ret val;
        ret_val = ioctl(file_desc, IOCTL_SET_MSG, message);
        if (ret_val < 0) {
                printf("ioctl_set_msg failed:%d\n", ret_val);
                exit(-1);
        }
ioctl get msg(int file desc)
        int ret val;
        char message[100];
        * Warning - this is dangerous because we don't tell
        * the kernel how far it's allowed to write, so it
         * might overflow the buffer. In a real production
         * program, we would have used two ioctls - one to tell
         * the kernel the buffer length and another to give
         * it the buffer to fill
         * /
        ret val = ioctl(file desc, IOCTL GET MSG, message);
        if (ret_val < 0) {
                printf("ioctl_get_msg failed:%d\n", ret_val);
                exit(-1);
        }
        printf("get msg message:%s\n", message);
ioctl_get_nth_byte(int file_desc)
       int i;
       char c;
        printf("get nth byte message:");
        i = 0;
        do {
                c = ioctl(file desc, IOCTL GET NTH BYTE, i++);
                if (c < 0) {
                        printf
                             ("ioctl get nth byte failed at the %d'th byte:\n",
                             i);
                        exit(-1);
                }
                putchar(c);
        } while (c != 0);
        putchar('\n');
```

```
/*

* Main - Call the ioctl functions

*/
main()
{
    int file_desc, ret_val;
    char *msg = "Message passed by ioctl\n";

    file_desc = open(DEVICE_FILE_NAME, 0);
    if (file_desc < 0) {
        printf("Can't open device file: %s\n", DEVICE_FILE_NAME);
        exit(-1);
    }

    ioctl_get_nth_byte(file_desc);
    ioctl_get_msg(file_desc);
    ioctl_set_msg(file_desc, msg);

    close(file_desc);
}
</pre>
```

Задание

- 1. Изучите приведённые примеры взаимодействия с драйверами устройств.
- 2. Выполните одно из следующих заданий (вариант взять у преподавателя). Требуется реализовать драйвер, поддерживающий функции открытия, закрытия, записи, чтения и имеющий документацию. При записи в драйвер могут передаваться команды. Для этого нужно проводить общий анализ передаваемых в него строк, чтобы определять какие команды передаются. Одна из них direction [forward/back] направление дальнейшего чтения из драйвера. Например последовательность команд с драйвером

echo "direction back" > /dev/chardev

cp /dev/chardev text

приведёт к чтению строки или буфера драйвера в обратном порядке, если драйвер поддерживает работу со строками. То же для файлов.

а) Драйвер поддерживает чтение и запись сообщений в него через существующие утилиты POSIX:

echo "message text_message" > /dev/chardev

Хранит только одно сообщение. Поддерживает функцию удаления сообщения: msg_delete.

- b) Драйвер поддерживает чтение и запись сообщений в него через пользовательский процесс: ioctl_set_msg(file_desc, msg). Поддерживает функцию удаления сообщения: ioctl_msg_delete.
- с) Драйвер поддерживает чтение и запись файлов в него через

существующие утилиты POSIX:

cat file > /dev/chardev

Хранит только один файл. Поддерживает функцию удаления файла: file delete.

- d) Драйвер поддерживает чтение и запись файла в него через пользовательский процесс: ioctl_write_file(file_desc, file_write_desc). Поддерживает функцию удаления сообщения: ioctl_file_delete.
- е) Драйвер поддерживает чтение файла в формате ASCII и запись сообщений в него через существующие утилиты POSIX:

echo "message text message" > /dev/chardev

Хранит только одно сообщение. Поддерживает функцию удаления сообщения: msg_delete.

Драйвер поддерживает чтение файла в формате ASCII и запись сообщений в него через пользовательский процесс: ioctl_set_msg(file_desc, msg). Поддерживает функцию удаления сообщения: ioctl_msg_delete.

Исходный код должен быть реализован в нескольких файлах. Следует обязательно разделить: документацию драйвера, функции инициализации и закрытия, функцию чтения, функцию записи, анализ команд.

Представить отчёт по лабораторной работе, содержащий задание, метод выполнения, возникшие сложности и пути их решения. Сделать собственные выводы о пользе или неэффективности реализованного механизма взаимодействия с драйвером.