Wiring Pi

GPIO Interface library for the Raspberry Pi



Raspberry Pi Specifics

These functions are not part of the core *wiringPi* set, but act specifically on the Raspberry Pi hardware itself. Some external hardware driver modules may provide some of this functionality though.

void digitalWriteByte (int value);

This writes the 8-bit byte supplied to the first 8 GPIO pins. It's the fastest way to set all 8 bits at once to a particular value, although it still takes two write operations to the Pi's GPIO hardware.

pwmSetMode (int mode);

The PWM generator can run in 2 modes — "balanced" and "mark:space". The mark:space mode is traditional, however the default mode in the Pi is "balanced". You can switch modes by supplying the parameter: **PWM_MODE_BAL** or **PWM_MODE_MS**.

pwmSetRange (unsigned int range);

This sets the range register in the PWM generator. The default is 1024.

pwmSetClock (int divisor);

This sets the divisor for the PWM clock.

Note: The PWM control functions can not be used when in Sys mode. To understand more about the PWM system, you'll need to read the Broadcom ARM peripherals manual.

piBoardRev (void);

This returns the board revision of the Raspberry Pi. It will be either 1 or 2. Some of the BCM_GPIO pins changed number and function when moving from board revision 1 to 2, so if you are using BCM_GPIO pin numbers, then you need to be aware of the differences.

wpiPinToGpio (int wPiPin);

This returns the BCM_GPIO pin number of the supplied *wiringPi* pin. It takes the board revision into account.

physPinToGpio (int physPin);

This returns the BCM_GPIO pin number of the supplied physical pin on the P1 connector.

• setPadDrive (int group, int value);

This sets the "strength" of the pad drivers for a particular group of pins. There are 3 groups of pins and the drive strength is from 0 to 7. Do not use this unless you know what you are doing.