Device: ARC360 PTZ CAMERA



Introduction

The Agile ARC360 PTZ Camera Device is still in Beta and only a few selected actions are working. The Device Core is work in progress and improvements are being made.

The development have carried out on a camera with software version 1.0.44

Current User: N/A

Compiler Version: 4.8.3 MPLAB XC32 Compiler v1.44

Harmony Version: 2.05 TCP Stack Version: 7.30


Build Date: Jan 31 2018 15:42:44

Software Version: 1.0.44

With current integration it is just possible to connect to *one* camera per Device Core.


SKAARHOJ DEVICE CORES

In order to confirm connection to the camera have been established look for the command "Connected to Agile" in the serial monitor. If no connection have been established the serial monitor will report "Agile timed out".




Camera Settings

A fixed IP must be set on the camera, and the Agile Device Core must have the same IP address as the camera.



SKAARHOJ DEVICE CORES

The Port Config must match the settings below. Camera Control Mode set to TCP and the two TCP ports must be enabled. Disable the UDP ports.



Actions

Currently, Pan, Tilt, Zoom (notice are currently assigned to pan/tilt), Focus, Focus One Push, Exposure Mode, Iris, Sensor Gain, Shutter IR, AWB Mode, AWB Exec and Gain are implemented.