Device: NewTek TriCaster Mini




Introduction

Our default configurations for NewTek TriCaster Mini usually involves activating a number of Macros. In the NewTek TriCaster Mini Device Core this action is called "TriCaster Mini: Trigger".



If the shortcut is not defined the same way as instructed in this manual, the desired action will not properly be triggered. A example below shows the "Trigger" necessary to be defined in order for our controller to activate that particular macro.



The relevant Macros can be found here: https://github.com/kasperskaarhoj/SKAARHOJ-Open-Engineering/tree/master/Manuals/NewTek