Федеральное государственное автономное образовательное учреждение высшего образования «Научно-образовательная корпорация ИТМО»

Факультет программной инженерии и компьютерной техники Направление подготовки 09.03.04 Программная инженерия

Отчёт по лабораторной работе $\mathbb{N}4$

По дисциплине «Системы ввода-вывода» (семестр 6)

Студент:

Дениченко Александр Р3312 Разинкин Александр Р3307 Балин Артём Р3312 Практик: Табунщик Сергей Михайлович

Цель

Изучение протоколов передачи данных между устройствами. Познакомится с принципами обмена данными между устройствами, алгоритмами обмена и форматами передачи данных на примере интерфейсов I2C, SPI, 1-Wire.

1 Задачи

- 1. Написать программу для микроконтроллера Atmega328, принимающую и отправляющую пакеты по интерфейсу UART в соответствии с обозначенным форматом пакета. Драйвер UART должен быть реализован с использованием операций ввода/вывода в регистры аппаратного контроллера UART.
- 2. Контроллер должен принимать данные с ПК, проверять их на корректность и отправлять обратно корректные пакеты. Если пакет пришел с ошибкой, то он отбрасывается.
 - 3. Контроллер должен раз в секунду передавать данные с датчика, указанного в варианте задания.
- 4. Написать клиентскую программу на ПК для приема и отправки пакетов к микроконтроллеру по интерфейсу UART, моделирующей как корректную отправку пакетов, так и случаи с ошибками: неправильная длина, отсутствие синхробайта, недостаточное количество данных.
 - 5. Подключить микроконтроллер к ПК и протестировать работоспособность написанных программ
 - 6. Снять осциллограмму передачи любого пакета по интерфейсу UART
 - 7. Оформить отчет по работе в электронном формате

2 Вариант 2

Датчик BMP280, SPI температура и давление – Скорость UART 38400 – Четность odd parity – Кол-во стоповых бит 2

3 Выполнение

Листинг 1: sketch

```
#include <Wire.h>
    #include <Adafruit BMP280.h>
    #define BMP CS 10
    Adafruit BMP280 bmp(BMP CS);
    void UART Init();
    void UART Transmit(char data);
    void UART SendString_P(const char* str);
    void UART_SendInt(int num);
11
    void UART SendFloat(float num);
12
13
    void setup() {
14
        UART Init();
15
        delay (100);
16
17
        unsigned status;
18
        status = bmp.begin();
19
        if (!status) {
20
             UART SendString P(PSTR("Could not find BMP280 sensor! \ r \ "));
21
             while (1);
22
        }
23
24
        bmp.setSampling(Adafruit BMP280::MODE NORMAL,
                          Adafruit BMP280::SAMPLING X2,
26
```

```
Adafruit BMP280::SAMPLING X16,
27
                           Adafruit BMP280::FILTER X16,
28
                           Adafruit_BMP280::STANDBY_MS_500);
29
30
31
    void loop() {
32
         UART SendString P(PSTR("Temperature = "));
33
         UART SendFloat(bmp.readTemperature());
34
         UART SendString P(PSTR(" *C\r\n"));
35
36
         UART SendString P(PSTR("Pressure = "));
         UART SendLong((long)bmp.readPressure());
38
         UART SendString P(PSTR("Pa\r\n\r\n"));
40
         delay (2000);
41
    }
42
    void UART Init() {
44
         uint16\_t \ ubrr = F\_CPU \ / \ 16 \ / \ 9600 \ - \ 1;
45
         UBRR0H = (uint8_t)(ubrr >> 8);
46
         UBRR0L = (uint8 t)ubrr;
47
         UCSR0B = (1 \ll TXEN0);
48
         UCSR0C = (1 << UCSZ01) | (1 << UCSZ00);
49
    }
50
51
    void UART Transmit(char data) {
52
         while (!(UCSR0A \& (1 \ll UDRE0)));
53
         UDR0 = data;
54
    }
55
56
    void UART SendString P(const char* str) {
57
         char c;
         while ((c = pgm\_read\_byte(str++))) {
59
              UART Transmit(c);
60
61
    }
62
63
    void UART SendInt(int num) {
64
         if (num < 0) {
65
             UART Transmit('-');
66
             num = -num;
67
         }
68
         char buffer [10];
69
         int i = 0;
70
71
         do {
72
              buffer [i++] = \text{num } \% 10 + '0';
73
             num /= 10;
74
         } while (num > 0);
76
         while (i > 0) {
             UART Transmit (buffer [--i]);
78
79
80
    void UART SendLong(long num) {
81
         if (\text{num} < 0) {
82
```

```
UART_Transmit('-');
83
              num = -num;
84
          char buffer [12];
86
          int i = 0;
         do {
              buffer [i++] = \text{num } \% 10 + '0';
90
              num = 10;
          \} while (num > 0);
92
          while (i > 0) {
94
              UART_Transmit(buffer[--i]);
96
     }
97
98
     void UART SendFloat(float num) {
99
          if (num < 0) {
100
              UART_Tansmit('-');
101
              num = -num;
102
          }
103
104
         long integerPart = (long)num;
105
         UART SendLong(integerPart);
106
         UART Transmit ('.');
107
          int decimalPart = (int)((num - integerPart) * 100 + 0.5);
109
          if (decimalPart < 10) UART Transmit('0');
         UART SendInt(decimalPart);
111
```

4 +client mode

Листинг 2: update ino

```
* UART communication program for Atmega328
    * - Receives packets with format: [SYNC(0x5A)][LENGTH][DATA][CHECKSUM]
    * - Validates packets and echoes back valid ones
    * - Sends sensor data every second
    * - Uses odd parity and 2 stop bits
    */
   // Constants
  #define F CPU 16000000UL
                             // 16 MHz clock
                              // Baud rate
  #define BAUD 38400
  #define SYNC BYTE 0x5A
                             // Sync byte for packet validation
12
   // Calculated UBRR value for UART
14
  #define UBRR VAL ((F CPU / (16UL * BAUD)) - 1)
16
   // Timer constants for 1-second interval
17
  #define TIMER1 PRESCALER 256
18
  #define TIMER1 COMPARE VALUE (F CPU / TIMER1 PRESCALER) // For 1 second
19
20
```

```
// Buffer sizes
   #define MAX PACKET SIZE 64
   \#define MAX_DATA_SIZE (MAX_PACKET_SIZE - 3) // Subtract sync, length, checksum
23
24
   // Packet parsing states
25
   typedef enum {
26
     STATE WAITING SYNC,
27
     STATE READING LENGTH,
28
     STATE READING DATA,
29
     STATE READING CHECKSUM
30
   } PacketState;
31
32
   // Global variables
33
   volatile uint8_t rxBuffer [MAX_PACKET_SIZE]; // Buffer for incoming data
34
   volatile \ uint8\_t \ dataBuffer [MAX\_DATA\_SIZE]; \ // \ Buffer \ for \ packet \ data
                                                  // Length of current data
   volatile uint8 t dataLength = 0;
36
   volatile PacketState state = STATE WAITING SYNC;
                                                 // Bytes read in current state
   volatile uint8 t by tesRead = 0;
38
   volatile \ uint8\_t \ sendSensorData = 0; \\ \hspace{2cm} // \ Flag \ for \ sending \ sensor \ data
39
40
   // Function prototypes
41
   void uartInit(void);
42
   void timerInit(void);
43
   uint8 t calculateChecksum(uint8 t *data, uint8 t length);
44
   void sendPacket(uint8 t *data, uint8 t length);
45
   uint16 t readSensor(void);
46
47
   void setup() {
     // Initialize UART with direct register access
49
     uartInit();
50
51
     // Initialize timer for 1-second sensor data transmission
     timerInit();
53
     // Initialize ADC for sensor readings
55
     // Enable ADC with prescaler 128 (16MHz/128 = 125kHz)
     ADCSRA = (1 << ADEN) \mid (1 << ADPS2) \mid (1 << ADPS1) \mid (1 << ADPS0);
57
     ADMUX = (1 << REFS0); // Use AVCC as reference, ADCO as input
58
59
60
61
   void loop() {
     // Check if it's time to send sensor data
62
     if (sendSensorData) {
63
       sendSensorData = 0;
64
       // Read from sensor
66
       uint16 t sensorValue = readSensor();
67
68
       // Prepare packet with sensor data
       uint8_t sensorPacket[3]; // 2 bytes for the sensor value + 1 for packet type
70
       sensorPacket[0] = 0x01; // Packet type: Sensor data
       sensorPacket[1] = (uint8_t)(sensorValue >> 8); // High byte
72
       sensorPacket [2] = (uint8 t)(sensorValue & 0xFF); // Low byte
73
74
       // Send the packet
75
       sendPacket (sensorPacket, sizeof (sensorPacket));
76
```

```
}
    }
79
    // Initialize UART with direct register access
80
    void uartInit(void) {
81
      // Set baud rate
82
      UBRR0H = (uint8 t)(UBRR VAL >> 8);
83
      UBRR0L = (uint8 t)UBRR VAL;
84
85
      // Enable transmitter and receiver, and receive interrupt
86
      UCSROB = (1 \ll RXENO) \mid (1 \ll TXENO) \mid (1 \ll RXCIEO);
88
      // Set frame format: 8 data bits, odd parity, 2 stop bits
89
      UCSROC = (1 \ll UCSZO1) | (1 \ll UCSZO0) | // 8-bit data
90
                (1 << \text{UPM01}) \mid (1 << \text{UPM00}) \mid
                                                    // Odd parity
                                                     // 2 stop bits
                (1 \ll USBS0);
92
    }
94
    // Initialize timer for 1-second intervals
95
    void timerInit(void) {
96
      // Set timer1 to CTC mode
      TCCR1A = 0;
98
      TCCR1B = (1 \ll WGM12) \mid (1 \ll CS12); // CTC mode, prescaler 256
99
100
      // Set compare value for 1 second
101
      OCR1A = TIMER1 COMPARE VALUE;
102
103
      // Enable timer compare interrupt
      TIMSK1 = (1 \ll OCIE1A);
105
106
      // Enable global interrupts
107
      sei();
109
    // UART receive interrupt
  ISR(USART_RX_vect) {
111
     // Read received byte
     uint8 t receivedByte = UDR0;
113
114
     // Check for UART errors (frame error, parity error, data overrun)
115
     uint8 t error = UCSR0A & ((1 \ll FE0) | (1 \ll UPE0) | (1 \ll DOR0));
116
117
     if (error) {
118
       // Reset state machine if there's an error
       state = STATE WAITING SYNC;
120
       return;
121
122
123
     // Process based on current state
124
     switch (state) {
125
       case STATE WAITING SYNC:
126
         if (receivedByte = SYNC BYTE) {
           rxBuffer[0] = SYNC BYTE;
128
           state = STATE READING LENGTH;
130
         break;
131
132
```

```
case STATE READING LENGTH:
133
         dataLength = receivedByte;
134
         rxBuffer[1] = dataLength;
135
136
         if (dataLength > MAX DATA SIZE) {
137
           // Invalid length, reset state machine
138
           state = STATE WAITING SYNC;
139
         } else {
140
           bytesRead = 0;
141
           state = STATE READING DATA;
142
         break;
144
       case STATE READING DATA:
146
         // Store data byte
         dataBuffer[bytesRead] = receivedByte;
148
         rxBuffer[2 + bytesRead] = receivedByte;
         bytesRead++;
150
151
         if (bytesRead >= dataLength) {
152
           state = STATE READING CHECKSUM;
153
154
         break;
155
156
       case STATE READING CHECKSUM:
157
         // Store and check checksum
         uint8 t receivedChecksum = receivedByte;
159
         uint8 t calculatedChecksum = calculateChecksum(dataBuffer, dataLength);
161
         if (received Checksum = calculated Checksum) {
            // Valid packet received, echo it back
163
           sendPacket(dataBuffer, dataLength);
         }
165
         // Reset for next packet
167
         state = STATE WAITING SYNC;
168
         break;
169
170
171
172
   // Timer1 compare interrupt for periodic sensor reading
173
  ISR (TIMER1 COMPA vect) {
174
     sendSensorData = 1;
176
177
   // Calculate checksum (XOR of all data bytes)
178
   uint8 t calculateChecksum(uint8 t *data, uint8 t length) {
     uint8 t checksum = 0;
180
     for (uint8_t i = 0; i < length; i++) {
       checksum ^= data[i];
182
     return checksum;
184
185
186
187 // Send a packet with the standard format
void sendPacket(uint8 t *data, uint8 t length) {
```

```
// Wait until transmit buffer is empty
189
     while (!(UCSR0A \& (1 << UDRE0)));
190
     UDR0 = SYNC BYTE;
191
192
     // Wait until transmit buffer is empty
193
     while (!(UCSR0A \& (1 \ll UDRE0)));
194
     UDR0 = length;
195
196
     // Send data bytes
197
     for (uint8 t i = 0; i < length; i++) {
198
       // Wait until transmit buffer is empty
       while (!(UCSR0A \& (1 << UDRE0)));
200
       UDR0 = data[i];
201
     }
202
     // Send checksum
204
     uint8 t checksum = calculateChecksum(data, length);
205
     while (!(UCSR0A \& (1 << UDRE0)));
206
     UDR0 = checksum;
207
208
209
   // Read sensor data from ADC
210
   uint16 t readSensor(void) {
211
     // Start conversion
212
     ADCSRA \mid = (1 \ll ADSC);
213
     // Wait for conversion to complete
215
     while (ADCSRA \& (1 << ADSC));
217
     // Return result
218
     return ADC;
219
220 }
```

Листинг 3: client

```
import serial
    import time
    import random
    import struct
    class UARTClient:
        # Standard packet format:
        \# [SYNC BYTE(1)] [LENGTH(1)] [DATA(n)] [CHECKSUM(1)]
        SYNC BYTE = 0x5A
        def init (self, port='COM5', baudrate=38400):
11
            self.ser = serial.Serial(
12
                port=port,
                baudrate=baudrate,
                bytesize=serial.EIGHTBITS,
                parity=serial.PARITY ODD, # Odd parity
16
                stopbits=serial.STOPBITS TWO, # 2 stop bits
                timeout=1
18
            if not self.ser.is open:
20
                 self.ser.open()
            print(f"Connected to {port} at {baudrate} baud, odd parity, 2 stop bits")
22
```

```
time.sleep(2) # Give time for Arduino to reset
def del(self):
    if hasattr(self, 'ser') and self.ser.is_open:
        self.ser.close()
        print("Serial port closed")
def calculate checksum (self, data):
    """Calculate simple XOR checksum of all data bytes"""
   checksum = 0
   for byte in data:
        checksum ^= byte
   return checksum
def send packet (self, data, corrupt type=None):
   Send a packet with optional corruption for testing
   corrupt type options:
   - None: Send normal, valid packet
   - 'no sync': Omit the sync byte
   - 'wrong length': Set incorrect length
   - 'wrong checksum': Use incorrect checksum
   - 'short data': Send less data than specified in length
   # Prepare basic packet
   packet = bytearray()
   # Add sync byte (unless corrupting)
   if corrupt type != 'no sync':
        packet.append(self.SYNC BYTE)
    else:
        packet.append(0x00) # Invalid sync byte
   # Add length byte
    if corrupt type = 'wrong length':
        packet.append(len(data) + 2) # Incorrect length
    else:
        packet.append(len(data)) # Correct length
   # Add data
    if corrupt_type == 'short_data':
       # Only add half the data
        packet.extend(data[:len(data)//2])
    else:
        packet.extend(data)
   # Add checksum
    if corrupt_type == 'wrong_checksum':
        packet.append((self.calculate checksum(data) + 1) % 256) # Incorrect checksum
    else:
        packet.append(self.calculate checksum(data)) # Correct checksum
   # Send the packet
   self.ser.write(packet)
```

25

26

27

28 29

30

31

32

34

36

38

40

41

42

44

45

46 47

49

51

53

57

59

60

61 62

64

66

67

68

70

72

74

76

```
# Print what was sent
print(f"Sent: {' '.join([f'{b:02X}]' for b in packet])}")
return len (packet)
def receive packet (self, timeout=1.0):
"""Receive and parse response packet with timeout"""
start time = time.time()
# Wait for sync byte
while (time.time() - start time) < timeout:
    if self.ser.in_waiting > 0:
        sync = self.ser.read(1)
        if sync and sync [0] = self.SYNC BYTE:
else:
    print ("Timeout waiting for sync byte")
    return None
# Read length
if self.ser.in_waiting < 1:
    time.sleep (0.1) # Small delay to ensure data arrival
    if self.ser.in\_waiting < 1:
        print ("Failed to receive length byte")
        return None
length = self.ser.read(1)[0]
# Read data
data = bytearray()
if length > 0:
    wait time = 0
    while len(data) < length and wait_time < timeout:
        if self.ser.in waiting > 0:
            data.extend(self.ser.read(min(length - len(data),
                self.ser.in waiting)))
        else:
            time. sleep (0.01)
            wait time += 0.01
    if len(data) < length:
        print(f"Incomplete data: received {len(data)}/{length} bytes")
        return None
# Read checksum
if self.ser.in waiting < 1:
    time. sleep (0.1)
    if self.ser.in_waiting < 1:
        print("Failed to receive checksum byte")
        return None
checksum = self.ser.read(1)[0]
# Verify checksum
calculated checksum = self.calculate checksum(data)
if checksum != calculated checksum:
    print(f"Checksum error: received {checksum:02X}, calculated
```

80

82

83

86

90

94

98

100

101

102 103

104 105

107

108

109

111

114

115 116

117

119 120

121

122

123

125

127

129

130

131

132

```
{calculated checksum:02X}")
        return None
   # Packet received successfully
   packet = bytearray([self.SYNC BYTE, length]) + data + bytearray([checksum])
   print(f"Received: {' '.join([f'{b:02X}}' for b in packet])}")
   return data
def test communication (self):
    """Run a series of tests including normal and corrupted packets"""
    tests = [
        ("Normal valid packet", None),
        ("Missing sync byte", "no_sync"),
("Incorrect length", "wrong_length"),
        ("Incorrect checksum", "wrong_checksum"),
        ("Incomplete data", "short data")
   for test name, corruption in tests:
        print(f"\n===Testing: \{test name\} ====")
       # Create random test data (3-10 bytes)
        data = bytearray ([random.randint (0, 255) for in range (random.randint (3,
           10))))
        print (f"Test data: {' '.join ([f'{b:02X}]' for b in data])}")
       # Send the packet with specified corruption
        self.send_packet(data, corruption)
        time. sleep (0.5)
       # Try to receive response
        response = self.receive packet()
        if response:
            print(f"Response received: {' '.join([f'{b:02X}]' for b in response])}")
        else:
            print ("No valid response received (as expected for corrupted packets)")
        time.sleep(1) # Pause between tests
        def receive packet (self, timeout=1.0):
        """Receive and parse response packet with timeout"""
        start time = time.time()
       # Wait for sync byte
        while (time.time() - start time) < timeout:
            if self.ser.in waiting > 0:
                sync = self.ser.read(1)
                if sync and sync [0] = self.SYNC BYTE:
        else:
            print ("Timeout waiting for sync byte")
            return None
       # Read length
        if self.ser.in_waiting < 1:
            time.sleep(0.1) # Small delay to ensure data arrival
            if self.ser.in waiting < 1:
```

136

137

138 139

140 141

142

144

146

148

150

152

153

154

155

156

158

160 161

162

164

166

167 168

169

170

171

172 173

175

176

177

179

181

183

184

185

186

```
print ("Failed to receive length byte")
                return None
        length = self.ser.read(1)[0]
       # Read data
        data = bytearray()
        if length > 0:
            wait \ time \, = \, 0
            while len(data) < length and wait time < timeout:
                if self.ser.in waiting > 0:
                    data.extend(self.ser.read(min(length - len(data),
                        self.ser.in waiting)))
                else:
                    time. sleep (0.01)
                    wait time += 0.01
            if len(data) < length:
                print(f"Incomplete data: received {len(data)}/{length} bytes")
                return None
       \# Read checksum
        if self.ser.in waiting < 1:
            time. sleep (0.1)
            if self.ser.in waiting < 1:
                print("Failed to receive checksum byte")
                return None
        checksum = self.ser.read(1)[0]
       # Verify checksum
        calculated_checksum = self.calculate_checksum(data)
        if checksum != calculated checksum:
            print(f"Checksum error: received {checksum:02X}, calculated
               {calculated checksum:02X}")
            return None
       # Packet received successfully
        packet = bytearray([self.SYNC_BYTE, length]) + data + bytearray([checksum])
        print(f"Received: {' '.join([f'{b:02X}' for b in packet])}")
        return data
def test communication (self):
    """Run a series of tests including normal and corrupted packets"""
    tests = [
        ("Normal valid packet", None),
        ("Missing sync byte", "no_sync"),
        ("Incorrect length", "wrong_length"),
        ("Incorrect checksum", "wrong_checksum"),
        ("Incomplete data", "short data")
   1
   for test name, corruption in tests:
        print(f"\n===resting: \{test name\} ====")
       # Create random test data (3-10 bytes)
```

189 190

191 192

193

194

195

196

197

199

200

202

204

205

206 207

208

209

210

211

213

215

217

219

222

223

224

225 226

227

229

230

231

233

235

237 238

239

240

```
data = bytearray ([random.randint(0, 255) for in range(random.randint(3,
   10))])
print(f"Test data: {' '.join([f'{b:02X}' for b in data])}")
# Send the packet with specified corruption
self.send packet (data, corruption)
time. sleep (0.5)
# Try to receive response
response = self.receive packet()
if response:
    print(f"Response received: {' '.join([f'{b:02X}]' for b in response])}")
else:
    print ("No valid response received (as expected for corrupted packets)")
time.sleep(1) # Pause between tests;
if name == "main":
trv:
    client = UARTClient()
    print ("\n== Running communication tests with various corruptions ==")
    client.test communication()
    print ("\n Starting regular communication mode == ")
    while True:
        # Send a normal packet with random data
        data = bytearray([random.randint(0, 255)] for in
            range(random.randint(3, 8))])
        print(f"\nSending data: \{'\ '.join([f'\{b:02X\}'\ for\ b\ in\ data])\}")
        client.send packet(data)
        # Receive response from microcontroller
        response = client.receive packet()
        if response:
            print (f"Response received: {' '.join ([f'{b:02X}]' for b in
                response]) }")
        # Wait for the 1-second sensor data that should come from
            microcontroller
        print ("Waiting for periodic sensor data...")
        sensor data = client.receive packet(timeout=1.5)
        if sensor data:
            print(f"Sensor data received: {' '.join([f'{b:02X}}' for b in
                sensor data])}")
        time.sleep(2)
except KeyboardInterrupt:
    print ("\nProgram terminated by user")
except serial. Serial Exception as e:
    print(f"Serial error: {e}")
    print ("Make sure the COM5 port is available and not in use by another
       program")
```

243

245

246

247 248

249

250

252

254

256

258

260

261

262 263

264

265

267

268

270

272

274

275

276

279


281

282

284

286

5 Logic 2



6 Example

```
Adatruit_bMP200 pilip(bMP_C3); //
        // Прототипы функций
   8
        void UART_Init();
   9
        void UART_Transmit(char data);
  10
       void UART_SendString_P(const char* str);
  11
       void UART_SendInt(int num);
  12
        void UART_SendFloat(float num);
  13
  14
       void setup() {
  15
            UART_Init();
  16
          delay(199).
  17
Output Serial Monitor X
Message (Enter to send message to 'Arduino Nano' on 'COM5')
Temperature = 26.84 *C
Pressure = 100722 Pa
Temperature = 26.86 *C
Pressure = 100723 Pa
```

7 Client out

Connected to COM5 at 38400 baud, odd parity, 2 stop bits

== Running communication tests with various corruptions ==

=== Testing: Normal valid packet ===

Test data: 55 00 C5 42 4F 83

Sent: 5A 06 55 00 C5 42 4F 83 1E

Received: 5A 06 55 00 C5 42 4F 83 1E Response received: 55 00 C5 42 4F 83