
<u>Chapter 4. Design of State-Space Servo-Controllers</u>

4.1 Introducing the Reference Signal

It is desired that the process output vector should follow a specified vector of setpoints:



Consider the SISO process:

$$\dot{\underline{x}} = A\underline{x} + Bu$$
$$y = Cx$$

For a steady state desired output y_{ss} we have:

Propose the control-law:

$$u(t) = u_{ss} - K(\underline{x}(t) - \underline{x}_{ss})$$

In the steady state:

$$\underline{O} = A\underline{x}_{ss} + Bu_{ss}$$
$$y_{ss} = C\underline{x}_{ss}$$

Let us propose the simple relationships:

$$u_{ss} = N_u r_{ss}$$
 $\underline{x}_{ss} = N_x r_{ss}$

This implies:

$$\underline{O} = AN_x r_{ss} + BN_u r_{ss}$$
$$y_{ss} = CN_x r_{ss}$$

Of course if we want the steady state output to be $r_{ss:}$

Then the gains N_x and N_u can be determined as:


$$\begin{bmatrix} N_x \\ N_u \end{bmatrix} = \begin{bmatrix} A & B \\ C & 0 \end{bmatrix}^{-1} \begin{bmatrix} 0 \\ 1 \end{bmatrix}$$

The control-law is then:

$$u(t) = N_u r(t) - K(x(t) - N_x r(t))$$

Which could of course be rewritten as:

This yields the following control structures:



<u>Tutorial:</u> Introduce a setpoint signal to the motor speed controller developed earlier – test in Simulink.

Some of the problems of this technique include:

- Does not increase the system type:
- Gains designed to reduce e_{ss} for setpoint changes:

4.2 State-Space Control with Integral Action

Consider again the SISO process:


$$\dot{\underline{x}}(t) = A\underline{x}(t) + Bu(t)$$
$$y(t) = Cx(t)$$

The state control-law with integral action is:

$$u(t) = -K\underline{x}(t) + K_I \int_0^t e(\tau)d\tau$$

where:

This could be represented as:



Introduce another state:

$$x_I(t) = \int_0^t e(\tau)d\tau$$

The control-law become:

$$u(t) = -K\underline{x}(t) + K_I x_I$$

This yields the closed-loop state equation:

$$\underline{\dot{x}}(t) = A\underline{x}(t) + B\left(-K\underline{x}(t) + K_Ix_I(t)\right)$$

But we know:

$$x_I(t) = \int_0^t e(\tau)d\tau$$

Hence the complete closed loop system can be represented by the coupled equations:

$$\underline{\dot{x}}(t) = (A - BK)\underline{x}(t) + BK_I x_I(t)
\dot{x}_I(t) = -C\underline{x}(t) + r(t)$$

Assign a new state vector:

$$\underline{z}(t) = \left[\frac{\underline{x}(t)}{x_I(t)}\right]$$

The closed-loop equations can be written more compactly as:

The poles of the closed-loop system are given by the roots of:

$$\det(sI - A_2) = 0$$

Determine the gains to place the N+1 closed-loop poles to obtain the following characteristic equation:

$$C_{des}(s) = s^{N+1} + C_N s^N + \cdots + C_1 s + C_0$$

Proof of Integral Action:

Consider an asymptotically constant setpoint signal:

Since the closed-loop system is stable – the states must converge to steady-state values:

$$\underline{0} = (A - BK)\underline{x}_{ss} + BK_I x_{Iss}
0 = -C\underline{x}_{ss} + r_{ss}$$

hence:

EXAMPLE: The DC Motor

$$\frac{d}{dt} \begin{bmatrix} \omega(t) \\ i(t) \end{bmatrix} = \begin{bmatrix} 0 & 50 \\ -200 & -200 \end{bmatrix} \begin{bmatrix} \omega(t) \\ i(t) \end{bmatrix} + \begin{bmatrix} 0 \\ 200 \end{bmatrix} v(t) + \begin{bmatrix} -50 \\ 0 \end{bmatrix} T_L(t)$$

$$y(t) = \begin{bmatrix} 1 & 0 \end{bmatrix} \begin{bmatrix} \omega(t) \\ i(t) \end{bmatrix}$$

Use the control-law

$$v(t) = -\left[k_1 \quad k_2\right] \begin{bmatrix} \omega(t) \\ i(t) \end{bmatrix} + K_I \int_0^t (r_{\omega}(\tau) - y(\tau)) d\tau$$

Then:

Hence the closed loop state-equation is:

$$\frac{d}{dt} \begin{bmatrix} \omega(t) \\ \frac{i(t)}{x_I(t)} \end{bmatrix} = \begin{bmatrix} 0 & 50 & 0 \\ -200 - 200k_1 & -200 - 200k_2 & 200K_1 \\ -1 & 0 & 0 & 0 \end{bmatrix} \begin{bmatrix} \omega(t) \\ \frac{i(t)}{x_I(t)} \end{bmatrix} + \begin{bmatrix} 0 \\ 0 \\ 1 \end{bmatrix} r(t) + \begin{bmatrix} -50 \\ 0 \\ -0 \end{bmatrix} T_L(t)$$

The poles of the closed-loop system are given by roots of:

$$\det \begin{bmatrix} s & 0 & | & 0 \\ 0 & s & | & 0 \\ \hline 0 & 0 & | & s \end{bmatrix} - \begin{bmatrix} 0 & 50 & | & 0 \\ -200 - 200k_1 & -200 - 200k_2 & | & 200K_I \\ \hline -1 & 0 & | & 0 \end{bmatrix} = 0$$

which yields:

$$\det \begin{bmatrix} s & -50 & 0 \\ 200 + 200k_1 & s + 200 + 200k_2 & -200K_I \\ 1 & 0 & s \end{bmatrix} = 0$$

the closed-loop characteristic equation is then:

Now we still want a second order dominant response with:

This can be achieved by placing the controller pole further out left:

The desired closed-loop characteristic equation is:

$$C_{des}(s) = (s + 400)(s^2 + 282.8s + 40000)$$

= $s^3 + 682.8s^2 + 153120s + 16000000$


Compare with the closed-loop characteristic equation:

$$10000K_1 = 16000000$$
$$10000(1 + k_1) = 153120$$
$$200(1 + k_2) = 682.8$$


This yields the controller:

$$v(t) = -14.3\omega(t) - 2.4i(t) + 1600 \int_{0}^{t} (r_{\omega}(\tau) - \omega(\tau)) d\tau$$

which could be built as follows:



The closed-loop responses are:



4.2.1 Use of Ackermans Method to Design Controllers with Integral Action

Define the open-loop equations as:

$$\dot{\underline{x}}(t) = A\underline{x}(t) + Bu(t)$$
$$\dot{x}_{I}(t) = r(t) - Cx(t)$$

Or in more compact form as:

$$\frac{d}{dt} \begin{bmatrix} --- \end{bmatrix} = \begin{bmatrix} --- \end{bmatrix} + \begin{bmatrix} --- \end{bmatrix} u(t) + \begin{bmatrix} --- \end{bmatrix} r(t)$$

Which is under the control:

$$u(t) = -K\underline{x}(t) + K_I x_I$$

or:

$$u(t) = -\left[K \mid -K_I\right]\underline{z}(t)$$

We can then use Ackermann's formula:

$$[K \mid -K_I] = [0 \quad 0 \quad \cdots \quad 0 \quad 1]C_z^{-1}C_{des}(A_2)$$

where:

$$C_{des}(s) = s^{N+1} + C_N s^N + \cdots + C_1 s + C_0 = 0$$


and:
$$C_{z} = B_{2} A_{2}B_{2} A_{2}B_{2} \cdots A_{2}^{N}B_{2}$$

4.2.2 Use of Inherent Integral Action

Consider the SISO process model:

$$\dot{\underline{x}} = A\underline{x} + Bu$$
$$y = C\underline{x}$$

of the special form:



The state of the Nth order process is then: $\underline{x}(t) = \begin{bmatrix} x_1 \\ -\frac{1}{2} \end{bmatrix}$

The output is: $y(t) = [c_1 \mid 0 \quad 0 \quad \cdots \quad 0] \underline{x}(t)$

We want the output y(t) to track the setpoint r(t). Consider that r(t) is asymptotically constant:

Consider the standard tracking controller structure:

$$u(t) = N_u r(t) - K(\underline{x}(t) - N_x r(t))$$

with the choice:

The control-law becomes:


$$u(t) = -K \left(\underline{x}(t) - \begin{bmatrix} 1/c_1 \\ 0 \\ \vdots \\ 0 \end{bmatrix} r(t) \right)$$

Or:

Which could be written as:

$$u(t) = -K \begin{bmatrix} \frac{y(t) - r(t)}{-\frac{c_1}{x_2(t)}} \\ \vdots \\ x_N(t) \end{bmatrix} = -\begin{bmatrix} \frac{k_1}{c_1} & K_2 \end{bmatrix} \begin{bmatrix} \frac{y(t) - r(t)}{x_2(t)} \\ \vdots \\ \frac{x_2(t)}{x_2(t)} \end{bmatrix}$$

This could be represented by:



Proof of Integral Action: