

QUIK-REVIEW



FUNCTIONS FOR CONNECTION/AUTHENTICATION SERVICES

SERVICE	PURPOSE	CONNECTION TYPE	LOCATION	VIEW
Windows® User Accounts	To establish host-level authentication	Workbench-to-platform	Windows ® Control Panel > User Accounts Windows-based Platform > User Manager	User Manager
Fox Service	To configure ports & authentication policy for a station	Workbench-to-station Station-to-station	Station > Config > Drivers > NiagaraNetwork	Property Sheet
Web Service	To configure ports & authentication scheme for a station	Browser-to-station	Station > Config > Services	Property Sheet
Station User Service	To authenticate credentials for both Fox and Web connections to a station	Workbench-to-station Station-to-station Browser-to-station	Station > Config > Services	Property Sheet for individual user account



